

SIEMENS



SINAMICS

Low-voltage SINAMICS G120C converters

Built-in devices, frame sizes AA ... C

Compact Operating Instructions

Edition

01/2016

SIEMENS

SINAMICS

SINAMICS G120C SINAMICS G120C inverter

Compact Operating Instructions

Fundamental safety instructions	1
Scope of delivery	2
Installing	3
Commissioning	4
Troubleshooting and additional information	5

Edition 01/2016, firmware 4.7 SP6

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.

 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.

 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.

NOTICE
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Fundamental safety instructions	7
1.1	General safety instructions	7
1.2	Industrial security	8
2	Scope of delivery	9
3	Installing	11
3.1	Mounting	11
3.2	Connecting	15
3.2.1	Optional components for the inverter	15
3.2.2	Connecting the inverter and inverter components to the line supply	16
3.2.3	Installing the converter in compliance with EMC rules	23
3.2.4	Overview of the interfaces	24
3.2.5	Terminal strips	25
3.2.6	Default setting of the interfaces	28
3.2.7	Wiring the terminal strip	35
3.2.8	Fieldbus interface assignment	36
4	Commissioning	37
4.1	Overview of the commissioning tools	37
4.2	Commissioning with BOP-2 operator panel	39
4.2.1	Quick commissioning with the BOP-2	39
4.2.2	Standard Drive Control	41
4.2.3	Dynamic Drive Control	43
4.2.4	Identifying the motor data and optimizing the closed-loop control	45
4.2.5	Additional settings	47
4.2.5.1	Operating the inverter with the BOP-2	47
4.2.5.2	Changing the function of individual terminals	50
4.2.5.3	Releasing the failsafe function "Safe Torque Off" (STO)	52
4.2.5.4	Parameter list	53
5	Troubleshooting and additional information	77
5.1	List of alarms and faults	77
5.2	Spare parts	83
5.3	Technical support	83
5.4	Overview of the manuals	84
	Index	85

This manual describes how you install and commission the SINAMICS G120C converter.

What is the meaning of the symbols in the manual?

 Reference to further information in the manual

 1 An operating instruction starts here.
2

 This concludes the operating instruction.

 Download from the Internet

 DVD that can be ordered

Fundamental safety instructions

1.1 General safety instructions

 WARNING
Risk of death if the safety instructions and remaining risks are not carefully observed If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur. <ul style="list-style-type: none">• Observe the safety instructions given in the hardware documentation.• Consider the residual risks for the risk evaluation.

 WARNING
Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death. <ul style="list-style-type: none">• Protect the parameterization (parameter assignments) against unauthorized access.• Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (<http://www.siemens.com/industrialsecurity>).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (<http://support.automation.siemens.com>).

WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.
You will find relevant information and newsletters at this address (<http://support.automation.siemens.com>).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
You will find further information at this address (<http://www.siemens.com/industrialsecurity>).
- Make sure that you include all installed products into the holistic industrial security concept.

Scope of delivery

The delivery comprises at least the following components:

- A ready to run inverter with loaded firmware.



Options for upgrading and downgrading the firmware can be found on the Internet: Firmware (<http://support.automation.siemens.com/WW/news/en/67364620>)

You can find the article number 6SL3210-1KE..., the hardware version (e.g. C02) and the firmware (e.g. V4.7) on the inverter rating plate.

- 1 set of connectors for connecting the inputs and outputs
- 1 set of connectors for connecting the line supply, motor and braking resistor
- Only for inverters with fieldbus via USS or Modbus RTU: 1 connector for connecting the fieldbus
- 1 set of shield plates
- Compact Operating Instructions in German and English
- The inverter contains open-source software (OSS). The OSS license terms are saved in the inverter.

Reading the OSS license terms

The inverter contains open-source software (OSS). OSS comprises open source text and satisfies special license terms. If you wish to read the license terms, you must transfer them from the inverter to a PC.

Procedure



1 To transfer the OSS license terms from the inverter to a PC, proceed as follows:

1. Switch off the inverter power supply.
2. Insert an empty memory card into the card slot of the inverter.



Overview of the interfaces (Page 24)

3. Switch on the inverter power supply.
4. When you have switched on the power supply, wait 30 seconds.




During this time, the inverter writes the "Read_OSS.ZIP" file onto the memory card.

5. Switch off the inverter power supply.
6. Withdraw the memory card from the inverter.
7. Use a card reader and load the file to a PC.



You have then transferred the OSS license terms from the inverter to a PC, and you can now read the license terms.

Rating plate and technical data

Frame size	Rated output power	Rated output current	Article No.	
	Based on a low overload		Without filter	With filter
 <p>FSAA</p>	0.55 kW	1.7 A	6SL3210-1KE11-8U <input type="checkbox"/> 2	6SL3210-1KE11-8A <input type="checkbox"/> 2
	0.75 kW	2.2 A	6SL3210-1KE12-3U <input type="checkbox"/> 2	6SL3210-1KE12-3A <input type="checkbox"/> 2
	1.1 kW	3.1 A	6SL3210-1KE13-2U <input type="checkbox"/> 2	6SL3210-1KE13-2A <input type="checkbox"/> 2
	1.5 kW	4.1 A	6SL3210-1KE14-3U <input type="checkbox"/> 2	6SL3210-1KE14-3A <input type="checkbox"/> 2
	2.2 kW	5.6 A	6SL3210-1KE15-8U <input type="checkbox"/> 2	6SL3210-1KE15-8A <input type="checkbox"/> 2
SINAMICS G120C USS/MB (USS, Modbus RTU)			B	B
SINAMICS G120C DP (PROFIBUS)			P	P
SINAMICS G120C PN (PROFINET, EtherNet/IP)			F	F
 <p>FSA</p>	0.55 kW	1.7 A	6SL3210-1KE11-8U <input type="checkbox"/> 1	6SL3210-1KE11-8A <input type="checkbox"/> 1
	0.75 kW	2.2 A	6SL3210-1KE12-3U <input type="checkbox"/> 1	6SL3210-1KE12-3A <input type="checkbox"/> 1
	1.1 kW	3.1 A	6SL3210-1KE13-2U <input type="checkbox"/> 1	6SL3210-1KE13-2A <input type="checkbox"/> 1
	1.5 kW	4.1 A	6SL3210-1KE14-3U <input type="checkbox"/> 1	6SL3210-1KE14-3A <input type="checkbox"/> 1
	2.2 kW	5.6 A	6SL3210-1KE15-8U <input type="checkbox"/> 1	6SL3210-1KE15-8A <input type="checkbox"/> 1
	3.0 kW	7.3 A	6SL3210-1KE17-5U <input type="checkbox"/> 1	6SL3210-1KE17-5A <input type="checkbox"/> 1
	4.0 kW	8.8 A	6SL3210-1KE18-8U <input type="checkbox"/> 1	6SL3210-1KE18-8A <input type="checkbox"/> 1
 <p>FSB</p>	5.5 kW	12.5 A	6SL3210-1KE21-3U <input type="checkbox"/> 1	6SL3210-1KE21-3A <input type="checkbox"/> 1
	7.5 kW	16.5 A	6SL3210-1KE21-7U <input type="checkbox"/> 1	6SL3210-1KE21-7A <input type="checkbox"/> 1
 <p>FSC</p>	11.0 kW	25.0 A	6SL3210-1KE22-6U <input type="checkbox"/> 1	6SL3210-1KE22-6A <input type="checkbox"/> 1
	15.0 kW	31.0 A	6SL3210-1KE23-2U <input type="checkbox"/> 1	6SL3210-1KE23-2A <input type="checkbox"/> 1
	18.5 kW	37.0 A	6SL3210-1KE23-8U <input type="checkbox"/> 1	6SL3210-1KE23-8A <input type="checkbox"/> 1
SINAMICS G120C USS/MB (USS, Modbus RTU)			B	B
SINAMICS G120C DP (PROFIBUS)			P	P
SINAMICS G120C PN (PROFINET, EtherNet/IP)			F	F
SINAMICS G120C CANopen			C	C

① **SIEMENS**
 Sinamics G120C ...
 Input : 3AC ...
 Output : 3AC ...
 Motor : ...
 Input : 3AC ...
 Motor: IEC ...



6SL3210-1KE... Version : ... / V...



Serial No : ... www.siemens.com/sinamics

The rating plate contains the Article No. and the hardware and firmware version of the inverter. You will find a rating plate at the following locations on the inverter:

- At the front, after removing the blanking cover for the operator panel.
- At the side on the heat sink

Installing

3.1 Mounting

Dimensions




Image 3-1 Dimensions and minimum spacing to other devices

Table 3- 1 Dimensions

	Frame size AA 0.55 kW ... 2.2 kW	Frame Size A 0.55 kW ... 4.0 kW	Frame size B 5.5 kW ... 7.5 kW	Frame size C 11 kW ... 18.5 kW
Height including connectors	181 mm	196 mm	196 mm	295 mm
Height including shield plate	268 mm	276 mm	276 mm	375 mm
Width	73 mm	73 mm	100 mm	140 mm
Depth of the inverter with PROFINET interface	178 mm	226 mm	226 mm	226 mm
Depth of the inverter with USS/MB, CANopen, or PROFIBUS interface	155 mm	203 mm	203 mm	203 mm
Additional depth when the Operator Panel is attached	+ 21 mm with IOP (Intelligent Operator Panel) attached			
	+ 11 mm with BOP-2 (Basic Operator Panel) attached			

Mounting the shield plates

We recommend that you mount the shield plates provided. The shield plates make it simpler to install the inverter in compliance with EMC regulations and to provide strength relief for the connected cables.






Image 3-2 Mounting the shield plates using as example a frame size A inverter

Mounting on a control cabinet panel

Table 3-2 Drilling patterns and mounting equipment

	Frame size AA 0.55 kW ... 2.2 kW	Frame Size A 0.55 kW ... 4.0 kW	Frame size B 5.5 kW ... 7.5 kW	Frame size C 11 kW ... 18.5 kW
Drilling pattern	<p>Drilling pattern without shield plate When the shield plate is mounted, the drilling pattern is compatible to frame size A</p>			
Mounting parts	2 x M4 bolts 2 x M4 nuts 2 x M4 washers	3 x M4 studs, 3 x M4 nuts, 3 x M4 washers	4 x M4 studs, 4 x M4 nuts, 4 x M4 washers	4 x M5 studs, 4 x M5 nuts, 4 x M5 washers
Locked-rotor (starting) torque	2.5 Nm	2.5 Nm	2.5 Nm	2.5 Nm

Mounting on a mounting rail (TS 35)



You can mount inverters, frame size FSAA on a TS 35 mounting rail.

Procedure



- 1 Proceed as follows to mount the inverter on a mounting rail:
1. Mount the inverter on the top edge of the mounting rail.
2. Using a screwdriver, actuate the release button on the upper side of the inverter.
3. Continue to actuate the release button until the inverter audibly snaps onto the mounting rail.




Image 3-3 Mounting on a standard mounting rail

You have mounted the inverter on a mounting rail.

- To remove, actuate the release button and at the same time withdraw the inverter from the mounting rail.

Mounting on a base component (only frame size FSAA)

Reactors, filters and braking resistors are available as base components for inverters, frame size FSAA.

Mount the inverter using two M4 screws on the base component.




Image 3-4 Available base components

You can combine up to two base components.




Image 3-5 Permissible combination of two base components

3.2 Connecting

3.2.1 Optional components for the inverter

Braking resistor

The braking resistor allows the inverter to actively brake loads with high moments of inertia

Line reactor

The line reactor increases the level of protection for the inverter against overvoltages, harmonics and commutation dips.

Note

In order that the inverter service life is not reduced, a line reactor is required for a relative short-circuit voltage u_k of the line transformer $< 1\%$.

Output choke

The output reactor increases the maximum permissible length of the motor cables.

Assignment of the inverter to braking resistor, line reactor and output reactor

6SL3210-... inverter			Line filter as base component
Frame sizes AA, A	0.55 kW ... 1.1 kW	...1KE11-8□□□, ...1KE12-3□□□, ...1KE13-2□□□	Class A: 6SE6400-2FA00-6AD0 Class B: 6SE6400-2FB00-6AD0
	1.5 kW ... 2.2 kW	...1KE14-3□□□, ...1KE15-8□□□	---
Frame sizes A ... C	3.0 kW ... 18.5 kW	...1KE17-5□□1, ...1KE18-8□□1, ...1KE21-3□□1, ...1KE21-7□□1, ...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	---

6SL3210-... inverter			Line reactor	Line filter as base component
Frame sizes AA, A	0.55 kW	...1KE11-8□□□	6SL3203-0CE13-2AA0	6SE6400-3CC00-2AD3
	0.75 kW ... 1.1 kW	...1KE12-3□□□, ...1KE13-2□□□		6SE6400-3CC00-4AD3
	1.5 kW	...1KE14-3□□□	6SL3203-0CE21-0AA0	6SE6400-3CC00-6AD3
	2.2 kW	...1KE15-8□□□		---
Frame size A	3.0 kW ... 4.0 kW	...1KE17-5□□1, ...1KE18-8□□1	---	---
Frame size B	5.5 kW ... 7.5 kW	...1KE21-3□□1, ...1KE21-7□□1	6SL3203-0CE21-8AA0	---
Frame size C	11.0 kW ... 18.5 kW	...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	6SL3203-0CE23-8AA0	---

6SL3210-... inverter			Output reactor	Output reactor as base component
Frame size AA, A	0.55 kW ... 1.1 kW	...1KE11-8□□□, ...1KE12-3□□□, ...1KE13-2□□□	6SL3202-0AE16-1CA0	6SE6400-3TC00-4AD2
	1.5 kW	...1KE14-3□□□		
	2.2 kW	...1KE15-8□□□		
Frame size A	3.0 kW ... 4.0 kW	...1KE17-5□□1, ...1KE18-8□□1	6SL3202-0AE18-8CA0	---
Frame size B	5.5 kW ... 7.5 kW	...1KE21-3□□1, ...1KE21-7□□1	6SL3202-0AE21-8CA0	
Frame size C	11.0 kW ... 18.5 kW	...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	6SL3202-0AE23-8CA0	

6SL3210-... inverter			Sine-wave filter as base component
Frame sizes AA, A	0.55 kW ... 1.5 kW	...1KE11-8□□□, ...1KE12-3□□□, ...1KE13-2□□□, ...1KE14-3□□□	6SE6400-3TD00-4AD0
	2.2 kW	...1KE15-8□□□	---
Frame sizes A ... C	3.0 kW ... 18.5 kW	...1KE17-5□□1, ...1KE18-8□□1, ...1KE21-3□□1, ...1KE21-7□□1, ...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	---

6SL3210-... inverter			Braking resistor	Braking resistor as base component
Frame sizes AA, A	0.55 kW ... 1.1 kW	...1KE11-8□□□, ...1KE12-3□□□, ...1KE13-2□□□	6SL3201-0BE14-3AA0	6SE6400-4BD11-0AA0
	1.5 kW	...1KE14-3□□□		
	2.2 kW	...1KE15-8□□□		
Frame size A	3.0 kW ... 4.0 kW	...1KE17-5□□1, ...1KE18-8□□1	6SL3201-0BE21-0AA0	---
Frame size B	5.5 kW ... 7.5 kW	...1KE21-3□□1, ...1KE21-7□□1	6SL3201-0BE21-8AA0	
Frame size C	11.0 kW ... 18.5 kW	...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	6SL3201-0BE23-8AA0	

3.2.2 Connecting the inverter and inverter components to the line supply




⚠ WARNING

Danger to life caused by high leakage currents for an interrupted protective conductor

The drive components conduct a high leakage current via the protective conductor. Touching conductive parts when the protective conductor is interrupted can result in death or serious injury.

- Dimension the protective conductor as specified.

Dimensioning the protective conductor



- ① For the protective conductor of the line-system connection within a machine or system, the following applies:
 1. Observe the local regulations for protective conductors subject to an increased leakage current at the site of operation.
 2. Lay the protective conductor as follows:
 - For permanent connection, the protective conductor must fulfill at least one of the following conditions:
 - The protective conductor is laid so that it is protected against mechanical damage over its complete length.¹⁾
 - In a multi-core cable, the protective conductor core has a cross-section of $\geq 2.5 \text{ mm}^2 \text{ Cu}$.
 - In a single conductor, the protective conductor has a cross-section of $\geq 10 \text{ mm}^2 \text{ Cu}$.
 - The protective conductor consists of two conductors with the same cross-section.
 - For the connection of a multi-core cable using an industrial plug connector according to EN 60309, the protective conductor must have a cross-section of $\geq 2.5 \text{ mm}^2 \text{ Cu}$.
 - 3) Cables laid within control cabinets or closed machine housings are considered to be adequately protected against mechanical damage.
- ② The protective conductor must have at least the same cross-section as the line cable of the inverter.

For a cross-section of the line cable $\geq 6 \text{ mm}^2$, cross-section = 6 mm^2 suffices for the protective conductor.
- ③ The protective conductor for the connection of the PE busbar to the control cabinet housing must have at least the same cross-section as the line supply cable of the machine or system (①).

For a cross-section of the line supply cable $\geq 6 \text{ mm}^2$, cross-section = 6 mm^2 suffices for the protective conductor.
- ④ The protective conductor must have at least the same cross-section as the motor cable of the inverter.

Overview





Image 3-6 Connecting the inverter and its optional components

The plugs for connecting the line supply, motor, and braking resistor are located on the lower side of the inverter.

If an EMC-compliant installation is required, you must use shielded cables.


Installing the converter in compliance with EMC rules (Page 23)




Connection cross-sections and tightening torque

Frame size, rated power		Converter Connection cross-section (tightening torque)			
FSA, FSA	0.55 kW ... 4.0 kW	1.0 ... 2.5 mm ²	(0.5 Nm)	18 ... 14 AWG	(4.5 lbf in)
FSB	5.5 kW ... 7.5 kW	4.0 ... 6.0 mm ²	(0.6 Nm)	12 ... 10 AWG	(5.5 lbf in)
FSC	11 kW	6.0 ... 16 mm ²	(1.5 Nm)	10 ... 5 AWG	(13.5 lbf in)
	15 kW ... 18.5 kW	10 ... 16 mm ²	(1.5 Nm)	7 ... 5 AWG	(13.5 lbf in)

Rated power of the inverter		Line reactor Connection cross-section (tightening torque)		
		0.55 kW ... 4.0 kW	2.5 mm ² (0.8 Nm)	14 AWG (7 lbf in)
5.5 kW ... 7.5 kW	6 mm ² (1.8 Nm)	10 AWG (16 lbf in)	PE M5 (5 Nm / 44 lbf in)	
11 kW ... 18.5 kW	16 mm ² (4 Nm)	5 AWG (35 lbf in)		

Rated power of the inverter		Output choke Connection cross-section (tightening torque)		
		0.55 kW ... 4.0 kW	2.5 mm ² (0.8 Nm)	14 AWG (7 lbf in)
5.5 kW ... 7.5 kW		10 mm ² (1.8 Nm)	8 AWG (16 lbf in)	PE M5 (5 Nm / 44 lbf in)
11 kW ... 18.5 kW		16 mm ² (4 Nm)	5 AWG (35 lbf in)	

Rated power of the inverter		Braking resistor Connection cross-section (tightening torque)			
		R1, R2, PE		Temperature contact	
0.55 kW ... 7.5 kW		2.5 mm ² (0.5 Nm)	14 AWG (4.5 lbf in)	2.5 mm ² (0.5 Nm)	14 AWG (4.5 lbf in)
11 kW ... 18.5 kW		6 mm ² (0.6 Nm)	10 AWG (5.5 lbf in)		

Converter Frame size, rated power			Reactor, filter or braking resistor as base components Connection cross-section (tightening torque)	
F5AA	0.55 kW ... 2.2 kW		1.0 ... 2.5 mm ² (1.1 Nm)	17 ... 14 AWG (10 lbf in)

Branch circuit protection according to the IEC standard

Table 3- 3 Permissible protection devices according to the IEC standard

Frame size	Rated power	Inverter article number	Article number		I _{max} ¹⁾	Control cabinet ²⁾
			Fuse	Circuit-breaker		
F5AA, F5A	0.55 kW	6SL3210-1KE11-8...	3NA3803	3RV2011-1JA.. or 3RV2021-1JA..	10 A	≥ 0.03 m ³
	0.75 kW	6SL3210-1KE12-3...				
	1.1 kW	6SL3210-1KE13-2...				
	1.5 kW	6SL3210-1KE14-3...				
	2.2 kW	6SL3210-1KE15-8...				
F5A	3 kW	6SL3210-1KE17-5...	3NA3805	3RV2011-4AA.. or 3RV2021-4AA..	16 A	
	4 kW	6SL3210-1KE18-8...				
F5B	5.5 kW	6SL3210-1KE21-3...	3NA3812	3RV2021-4EA..	32 A	≥ 0.06 m ³
	7.5 kW	6SL3210-1KE21-7...				
F5C	11 kW	6SL3210-1KE22-6...	3NA3822	3RV1041-4JA..	63 A	≥ 0.2 m ³
	15 kW	6SL3210-1KE23-2...				
	18.5 kW	6SL3210-1KE23-8...				

- 1) Maximum rated current of the protection device. You may also use protective devices 3NA38.. and 3RV with a lower rated current.
- 2) Minimum volume of the control cabinet in which the inverter is installed. The restriction applies only for a protection with a circuit-breaker.

Branch circuit protection according to the UL standard

Use in North America requires protection devices that meet UL standards as detailed in the following tables.

Table 3- 4 Permissible safety devices according to the UL standard

Protection device	UL category
Fuses of any manufacturer with faster tripping characteristic than class RK5, e.g. class J, T, CC, G, or CF	JDDZ
SIEMENS circuit breaker	DIVQ
Intrinsically safe SIEMENS circuit breaker	NKJH

In accordance with the following tables, you may operate the inverter on a branch circuit with the specified short-circuit current rating provided the specified branch-circuit protection is installed.

Table 3- 5 Permissible circuit protection with non-semiconductor fuses of Classes J, T, CC, G or CF (JDDZ)

Frame size	Rated power	Inverter article number	$I_{max}^{1)}$	SCCR ²⁾	Control cabinet ³⁾
FSAA, FSA	0.55 kW	6SL3210-1KE11-8...	10 A	100 kA, 480 V 3 AC	$\geq 1830 \text{ in}^3$
	0.75 kW	6SL3210-1KE12-3...			
	1.1 kW	6SL3210-1KE13-2...			
	1.5 kW	6SL3210-1KE14-3...			
	2.2 kW	6SL3210-1KE15-8...			
FSA	3 kW	6SL3210-1KE17-5...	15 A	100 kA, 480 V 3 AC	$\geq 1830 \text{ in}^3$
	4 kW	6SL3210-1KE18-8...			
FSB	5.5 kW	6SL3210-1KE21-3...	35 A	100 kA, 480 V 3 AC	$\geq 3660 \text{ in}^3$
	7.5 kW	6SL3210-1KE21-7...			
FSC	11 kW	6SL3210-1KE22-6...	60 A	100 kA, 480 V 3 AC	$\geq 12200 \text{ in}^3$
	15 kW	6SL3210-1KE23-2...			
	18.5 kW	6SL3210-1KE23-8...			

1) Maximum rated current of the fuse

2) Short-circuit current rating of the branch circuit

3) Minimum volume of the control cabinet in which the inverter is installed. The restriction does not apply to inverters FSA ... FSC with fuses of the class AJT from Mersen (Ferraz Shawmut).

Table 3- 6 Permissible circuit-breakers (DIVQ)

Frame size	Rated power	Inverter article number	Article number	$I_{max}^{1)}$	SCCR ²⁾	Control cabinet ³⁾
FSAA, FSA	0.55 kW	6SL3210-1KE11-8...	3RV1742, LGG or CED6	15 A	5 kA, 480 VAC	$\geq 1830 \text{ in}^3$
	0.75 kW	6SL3210-1KE12-3...	3RV2711	15 A	5 kA, 480Y / 277 VAC	$\geq 1830 \text{ in}^3$
	1.1 kW	6SL3210-1KE13-2...				
	1.5 kW	6SL3210-1KE14-3...				
	2.2 kW	6SL3210-1KE15-8...				

Frame size	Rated power	Inverter article number	Article number	$I_{max}^{1)}$	SCCR ²⁾	Control cabinet ³⁾
FSA	3 kW	6SL3210-1KE17-5...	3RV1742, LGG or CED6	15 A	65 kA, 480 VAC	$\geq 1830 \text{ in}^3$
	4 kW	6SL3210-1KE18-8...	3RV2711	15 A	65 kA, 480Y / 277 VAC	$\geq 1830 \text{ in}^3$
FSB	5.5 kW 7.5 kW	6SL3210-1KE21-3... 6SL3210-1KE21-7...	NCGA	35 A	35 kA, 480 VAC	$\geq 3660 \text{ in}^3$
			3RV2721	35 A	50 kA, 480Y / 277 VAC	$\geq 3660 \text{ in}^3$
			LGG, CED6 or HCGA	35 A	65 kA, 480 VAC	$\geq 3660 \text{ in}^3$
			3RV1742	35 A	65 kA, 480Y / 277 VAC ⁴⁾	$\geq 3660 \text{ in}^3$
			3RV2711	35 A	65 kA, 480Y / 277 VAC	$\geq 3660 \text{ in}^3$
FSC	11 kW 15 kW 18.5 kW	6SL3210-1KE22-6... 6SL3210-1KE23-2... 6SL3210-1KE23-8...	NCGA	60 A	35 kA, 480 VAC	$\geq 8780 \text{ in}^3$
			LGG, CED6 or HCGA	60 A	65 kA, 480 VAC	$\geq 8780 \text{ in}^3$
			3RV1742	60 A	65 kA, 480Y / 277 VAC ⁴⁾	$\geq 8780 \text{ in}^3$

- 1) Maximum rated current of the circuit-breaker
- 2) Short-circuit current rating of the branch circuit
- 3) Minimum volume of the control cabinet in which the inverter is installed. The restriction does not apply to inverters FSA ... FSC with fuses of the class AJT from Mersen (Ferraz Shawmut).
- 4) 65 kA, 480 VAC with rated current < 35 A

Table 3- 7 Permissible intrinsically safe circuit-breakers (NKJH)

Frame size	Rated power	Inverter article number	Article number	$I_{max}^{1)}$	$P_N^{2)}$	SCCR ³⁾	Control cabinet ⁴⁾
FSAA, FSA	0.55 kW 0.75 kW 1.1 kW 1.5 kW 2.2 kW	6SL3210-1KE11-8... 6SL3210-1KE12-3... 6SL3210-1KE13-2... 6SL3210-1KE14-3... 6SL3210-1KE15-8...	3RV2011-1JA.. or 3RV2021-1JA..	10 A	5 HP	65 kA, 480Y / 277 VAC	$\geq 1830 \text{ in}^3$
FSA	3 kW 4 kW	6SL3210-1KE17-5... 6SL3210-1KE18-8...	3RV2011-4AA.. or 3RV2011-4AA..	16 A	10 HP	65 kA, 480Y / 277 VAC	$\geq 1830 \text{ in}^3$
			3RV1031-4AA..	16 A	10 HP	65 kA, 480Y / 277 VAC	$\geq 1830 \text{ in}^3$
FSB	5.5 kW 7.5 kW	6SL3210-1KE21-3... 6SL3210-1KE21-7...	3RV2021-4DA..	25 A	15 HP	65 kA, 480Y / 277 VAC	$\geq 3660 \text{ in}^3$
			3RV2021-4EA..	32 A	20 HP	50 kA, 480Y / 277 VAC	$\geq 3660 \text{ in}^3$
			3RV1031-4EA.. or 3RV1031-4EA..	32 A	20 HP	65 kA, 480Y / 277 VAC	$\geq 3660 \text{ in}^3$
FSC	11 kW 15 kW 18.5 kW	6SL3210-1KE22-6... 6SL3210-1KE23-2... 6SL3210-1KE23-8...	3RV1031-4HA..	50 A	40 HP	65 kA, 480Y / 277 VAC	$\geq 12200 \text{ in}^3$
			3RV1041-4JA..	63 A	50 HP	65 kA, 480Y / 277 VAC	$\geq 12200 \text{ in}^3$

- 1) Maximum rated current of the circuit-breaker Consequently, you may use NKJH-listed SIEMENS circuit-breakers of the same type with a rated voltage $\geq 480 \text{ VAC}$ and with a lower rated current.
- 2) Rated power of the circuit-breaker at 460 VAC
- 3) Short-circuit current rating of the branch circuit
- 4) Minimum volume of the control cabinet in which the inverter is installed. The restriction does not apply to inverters FSA ... FSC with fuses of the class AJT from Mersen (Ferraz Shawmut).

Installation in the United States and Canada (UL or CSA)

To install the inverter in compliance with UL/cUL, perform the following steps:

- Use the specified protection devices.
- A multi-motor drive is not permissible, i.e. simultaneously operating several motors connected to one inverter.
- The integrated semiconductor short-circuit protection in the inverter does not provide branch protection. Install branch protection in compliance with the National Electric Code and possibly relevant local regulations.
- Use copper cables, Class 1, $\geq 60^\circ$ C for frame size FSAA with rated power ≤ 1.5 kW.
- Use copper cables, Class 1, 75° C for frame sizes FSAA (2.2 KW) and FSA ... FSC.
- Leave parameter p0610 in its factory setting.


The factory setting p0610 = 12 means: The inverter responds to motor overtemperature immediately with an alarm and after a certain time with a fault.

Additional requirements for CSA compliance:

- Use the specified protection devices.
- Use a surge protection device with article no. 5SD7424-1.
- Alternative: Install the inverter with an external surge protection device with the following attributes:
 - Surge protection device with 'listed' test symbol: category checking numbers VZCA and VZCA7
 - Rated voltage 3-phase 480/277 VAC, 50/60 Hz
 - Terminal voltage $V_{PR} = 2000$ V, $I_N = 3$ kA min, MCOV = 508 VAC, SCCR = 40 kA
 - Suitable for SPD applications, type 1 or type 2
- When commissioning the drive system, set the motor overload protection to 115%, 230% or 400% of the rated motor current using parameter p0640. This means that motor overload protection according to CSA C22.2 No. 274 is complied with.

3.2.3 Installing the converter in compliance with EMC rules

Overview



- ① Unshielded line supply cable
- ② Toothed tapes on the shield plate of the inverter
- ③ Shielded cable to the braking resistor
- ④ Shield clamp for the cable to the terminal strip on the shield plate of the inverter
- ⑤ Shielded cables to the terminal strip, to the fieldbus and to the motor temperature sensor
- ⑥ Shielded motor cable
- ⑦ Unlacquered, good electrically conducting mounting plate
- ⑧ Supplied ferrite core in the power cable, relevant only for FSAA, 2.2 kW (6SL3210-1KE15-8A□2)

Image 3-7 EMC-compliant wiring shown using the example of a frame size A inverter (frame size AA)





Image 3-8 EMC-compliant shield connection

3.2.4 Overview of the interfaces


Interfaces at the front of the Control Unit

To access the interfaces at the front of the Control Unit, you must unplug the Operator Panel (if one is being used) and open the front doors.



3.2.5 Terminal strips

Wiring variations of the terminal strips



GND All terminals with the reference potential "GND" are connected to each other inside the inverter.

DI COM1 The reference potentials "DI COM1" and "DI COM2" are galvanically isolated from "GND."

→ If you use the 24-V power supply at terminal 9 to power the digital inputs, you must interconnect "GND," "DI COM1," and "DI COM2."

Terminals 31, 32: When an optional 24-V power supply is connected to terminals 31, 32, the Control Unit remains in operation even after the Power Module has been disconnected from the line supply. The Control Unit thus maintains fieldbus communication, for example.

GND IN

→ Connect only power supplies that are SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) to terminals 31, 32 .


→ If you also wish to use the power supply at terminals 31, 32 for the digital inputs, then you must connect "DI COM1/2" and "GND IN" with one another.

Terminals 3, 4: For the analog input, you can use the internal 10-V power supply or an external voltage source. Typical current consumption: 10 mA ... 20 mA.

→ If you use the internal 10-V supply, you must connect AI 0- to GND.


Image 3-9 Example of wiring digital inputs with the inverter's internal 24-V power supply

Further wiring options for digital inputs



If you want to connect the potential of the external power source to the potential of the inverter's internal power supply, you must connect "GND" to terminals 34 and 69.

Connection of contacts switching to P potential with an external power source



Connect terminals 69 and 34 to each other.

Connection of contacts switching to N potential with an external power source

Factory settings of the terminal strip

The factory setting of the terminals depends on whether the inverter has a PROFIBUS / PROFINET interface.




Image 3-10 Factory setting of the terminals for G120C USS and G120C CAN




Image 3-11 Factory setting of the terminals for G120C DP and G120C PN

Changing the function of the terminals

The function of the terminals marked in color in the two diagrams above, can be set.

In order not to have to successively change terminal for terminal, several terminals can be jointly set using default settings ("p0015 Macro drive unit").

The terminal settings made in the factory described above correspond to the following default settings:

- Default setting 12 (p0015 = 12): "Standard I/O with analog setpoint"
- Default setting 7 (p0015 = 7): "Fieldbus with data set switchover"

3.2.6 Default setting of the interfaces

Default setting 1: "Conveyor technology with 2 fixed frequencies"

—	5	DI 0	ON/OFF1 clockwise
—	6	DI 1	ON/OFF1 counterclockwise
—	7	DI 2	Acknowledge fault
—	16	DI 4	Fixed speed setpoint 3
—	17	DI 5	Fixed speed setpoint 4
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Fixed speed setpoint 3: p1003, fixed speed setpoint 4: p1004, fixed speed setpoint active: r1024
 Speed setpoint (main setpoint): p1070[0] = 1024
 DI 4 and DI 5 = high: the inverter adds the two fixed speed setpoints
 Designation in the BOP-2: coN 2 SP

Default setting 2: "Conveyor system with Basic Safety"

—	5	DI 0	ON/OFF1 with fixed speed setpoint 1
—	6	DI 1	Fixed speed setpoint 2
—	7	DI 2	Acknowledge fault
—	16	DI 4	} Reserved for a safety function
—	17	DI 5	
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Fixed speed setpoint 1: p1001, fixed speed setpoint 2: p1002, fixed speed setpoint active: r1024
 Speed setpoint (main setpoint): p1070[0] = 1024
 DI 0 and DI 1 = high: the inverter adds the two fixed speed setpoints.
 Designation in the BOP-2: coN SAFE

Default setting 3: "Conveyor system with 4 fixed frequencies"

5	DI 0	ON/OFF1 with fixed speed setpoint 1
6	DI 1	Fixed speed setpoint 2
7	DI 2	Acknowledge fault
16	DI 4	Fixed speed setpoint 3
17	DI 5	Fixed speed setpoint 4
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5


Fixed speed setpoint 1: p1001, ... fixed speed setpoint 4: p1004, fixed speed setpoint active: r1024

Speed setpoint (main setpoint): p1070[0] = 1024

Several of the DI 0, DI 1, DI 4, and DI 5 = high: the inverter adds the corresponding fixed speed setpoints.

Designation in the BOP-2: coN 4 SP

Default setting 4: "Conveyor system with fieldbus"




DO 0: p0730, DO 1: p0731 AO 0: p0771[0]

Speed setpoint (main setpoint): p1070[0] = 2050[1]

Designation in the BOP-2: coN Fb

Default setting 5: "Conveyor system with fieldbus and Basic Safety"




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 4: r0722.4, DI 5: r0722.5

Speed setpoint (main setpoint): p1070[0] = 2050[1]

Designation in the BOP-2: coN Fb S


Default setting 7: "Fieldbus with data set switchover"

Factory setting for inverters with PROFIBUS or PROFINET interface




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 3: r0722.3
 Speed setpoint (main setpoint): p1070[0] = 2050[1]
 Jog 1 speed setpoint: p1058, factory setting: 150 rpm
 Jog 2 speed setpoint: p1059, factory setting: -150 rpm
 Designation in the BOP-2: FB cdS

Default setting 8: "MOP with Basic Safety"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 1050
 Designation in the BOP-2: MoP SAFE


Default setting 9: "Standard I/O with MOP"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 3: r0722.3
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 1050
 Designation in the BOP-2: Std MoP


Default setting 12: "Standard I/O with analog setpoint"

Factory setting for inverters with USS interface




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: Std ASP

Default setting 13: "Standard I/O with analog setpoint and safety"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: ASPS

Default setting 14: "Process industry with fieldbus"




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5

Motorized potentiometer, setpoint after the ramp-function generator: r1050

Speed setpoint (main setpoint): p1070[0] = 2050[1], p1070[1] = 1050


Designation in the BOP-2: Proc Fb

Default setting 15: "Process industry"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5 AI 0: r0755[0]
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 755[0], p1070[1] = 1050
 Designation in the BOP-2: Proc

Default setting 17: "2-wire (forw/backw1)"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 2-wlrE 1

Default setting 18: "2-wire (forw/backw2)"

5	DI 0	ON/OFF1 clockwise
6	DI 1	ON/OFF counterclockwise
7	DI 2	Acknowledge fault
3	AI 0+	Speed setpoint
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 2-wlrE 2

Default setting 19: "3-wire (enable/forw/backw)"

5	DI 0	Enable/OFF1
6	DI 1	ON clockwise
7	DI 2	ON counterclockwise
16	DI 4	Acknowledge fault
3	AI 0+	Speed setpoint
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value


DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 4: r0722.4 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 3-wlrE 1

Default setting 20: "3-wire (enable/on/reverse)"


5	DI 0	Enable/OFF1
6	DI 1	ON
7	DI 2	Reversing
16	DI 4	Acknowledge fault
3	AI 0+	Speed setpoint
18	DO 0	Fault
19		
20		
21	DO 1	Alarm
22		
12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 4: r0722.4 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 3-wlrE 2

Default setting 21: "USS fieldbus"



Default setting 22: "CAN fieldbus"



3.2.7 Wiring the terminal strip

Table 3- 8 Permissible cables and wiring options

Solid or finely stranded cable	Flexible conductor with non-insulated end sleeve	Flexible conductor with non-insulated end sleeve	Two finely stranded cables with the same cross-section with partially insulated twin end sleeves
<p>8 mm 0.5 ... 1.5 mm²</p>	<p>8 mm 0.5 ... 1.0 mm²</p>	<p>8 mm 0.5 mm²</p>	<p>8 mm 2 * 0.5 mm²</p>

Wiring the terminal strip to ensure EMC


- If you use shielded cables, then you must connect the shield to the mounting plate of the control cabinet or with the shield support of the inverter through a good electrical connection and a large surface area.
- Use the shield connection plate of the inverter as strain relief.



Further information about EMC-compliant wiring is available in the Internet:EMC installation guideline (<http://support.automation.siemens.com/WW/view/en/60612658>)

3.2.8 Fieldbus interface assignment

The fieldbus interface is on the underside of the converter.



Description files for fieldbuses

The description files are electronic device data sheets which contain all the required information of a higher-level controller. You can configure and operate the inverter on a fieldbus with the appropriate description file.



Description file	Download	Alternative to download
Generic Station Description (GSD) for PROFIBUS	Internet: (http://support.automation.siemens.com/WW/view/en/23450835)	GSD and GSDML are saved in the inverter. The inverter writes its GSD or GSDML to the memory card once you insert this card in the inverter and set p0804 = 12. You can then transfer the file to your programming device or PC using the memory card.
GSD Markup Language (GSDML) for PROFINET	Internet: (http://support.automation.siemens.com/WW/view/en/26641490)	
Electronic Data Sheet (EDS) for CANopen	Internet: (http://support.automation.siemens.com/WW/view/en/48351511)	---
EDS for Ethernet/IP	Internet: (http://support.automation.siemens.com/WW/view/en/78026217)	---

Commissioning

4.1 Overview of the commissioning tools

Operator panel

An operator panel is used to commission, troubleshoot and control the inverter, as well as to back up and transfer the inverter settings.



The Intelligent Operator Panel (IOP) is available for snapping on to the Control Unit or as handheld with a connection cable to the Control Unit. The graphics-capable plain text display of the IOP enables intuitive operation and diagnostics of the inverter.

The IOP is available in two versions:

- With European languages
- With Chinese, English and German

Additional information about the compatibility of the IOP and Control Units is available in the Internet:



Compatibility of the IOP and Control Units

(<http://support.automation.siemens.com/WW/view/en/67273266>)



The BOP-2 is an operator panel for snapping on to the Control Unit. The BOP-2 has a two-line display for operation and diagnostics of the inverter.

Operating Instructions of the BOP-2 and IOP operator panels:



Operator Panels

(<http://support.automation.siemens.com/WW/view/en/30563514/133300>)



STARTER and Startdrive PC tools

STARTER and Startdrive are PC tools that are used to commission, troubleshoot and control the inverter, as well as to back up and transfer the inverter settings. You can connect the PC with the inverter via USB or via the PROFIBUS / PROFINET fieldbus.

Connecting cable (3 m) between PC and inverter: Article number 6SL3255-0AA00-2CA0

DVD article number

STARTER: 6SL3072-0AA00-0AG0

Startdrive: 6SL3072-4CA02-1XG0



System requirements and download:

STARTER (<http://support.automation.siemens.com/WW/view/en/26233208>)

Startdrive (<http://support.automation.siemens.com/WW/view/en/68034568>)

Help regarding operation:

STARTER videos (<http://www.automation.siemens.com/mcms/mc-drives/en/low-voltage-inverter/sinamics-g120/videos/Pages/videos.aspx>)

Tutorial (<http://support.automation.siemens.com/WW/view/en/73598459>)

If you intend to commission the converter with IOP operator panel

The IOP offers commissioning wizards and help texts for an intuitive commissioning. For further information refer to the IOP operating instructions.

If you intend to commission the converter with PC tools STARTER and Startdrive

Overview of the most important steps with STARTER:

1. Connect the PC to the converter via USB and start the PC tool.
2. Choose the project wizard (menu "Project / New with assistant").
 - In the project wizard choose "Find drive units online".
 - Select USB as interface (Access point of the application: "DEVICE ...", interface parameter assignment used: "S7USB").
 - Finish the project wizard.
3. STARTER has now created your project and inserted a new drive.
 - Select the drive in your project and go online .
 - In your drive open the "Configuration" mask (double click).
 - Start commissioning with the "Assistent" button.

For further information refer to converter operating instructions.



Overview of the manuals (Page 84)

4.2 Commissioning with BOP-2 operator panel

Plug Basic Operator Panel BOP-2 into the inverter

Procedure

- ➔ 1 To plug Basic Operator Panel BOP-2 onto the inverter, proceed as follows:
- 2
1. Remove the blanking cover of the inverter.
 2. Locate the lower edge of the BOP-2 housing in the matching recess of the inverter housing.
 3. Press the BOP-2 onto the inverter until you hear the latching mechanism on the inverter housing engage.
- You have plugged the BOP-2 onto the inverter
- When you power up the inverter, the BOP-2 will be ready for operation.



4.2.1 Quick commissioning with the BOP-2

Carrying out quick commissioning

Preconditions

SP 000.0 1/min
0.0 1/min

- The power supply is switched on.
- The operator panel displays setpoints and actual values.



Procedure

- ➔ 1 Proceed as follows to carry out quick commissioning:
- 2
1. Press the ESC key.
 2. Press one of the arrow keys until the BOP-2 displays the "SETUP" menu.
 3. In the "SETUP" menu, press the OK key to start quick commissioning.
 4. If you wish to restore all of the parameters to the factory setting before the quick commissioning:
 - 4.1. Switchover the display using an arrow key: nO → YES
 - 4.2. Press the OK key.
 5. When you select an application class, the inverter assigns suitable default settings to the motor control:




STANDARD		Standard Drive Control (Page 41)
DYNAMIC		Dynamic Drive Control (Page 43)
EXPERT		This procedure is described in the operating instructions
		Overview of the manuals (Page 84)

Select the suitable application class

When you select an application class, the inverter assigns suitable settings to the motor control:

Application class	Standard Drive Control	Dynamic Drive Control
Motors that can be operated	Induction motors	Induction and synchronous motors
Application examples	<ul style="list-style-type: none"> • Pumps, fans, and compressors with flow characteristic • Wet or dry blasting technology • Mills, mixers, kneaders, crushers, agitators • Horizontal conveyor technology (conveyor belts, roller conveyors, chain conveyors) • Basic spindles 	<ul style="list-style-type: none"> • Pumps and compressors with displacement machines • Rotary furnaces • Extruder • Centrifuge
Characteristics	<ul style="list-style-type: none"> • Typical settling time after a speed change: 100 ms ... 200 ms • Typical settling time after a sudden load change: 500 ms • Standard Drive Control is suitable for the following requirements: <ul style="list-style-type: none"> – All motor power ratings – Ramp-up time 0 → rated speed (depending on the motor power rating): 1 s (0.1 kW) ... 10 s (18.5 kW) – Applications with continuous load torque without sudden load changes • Standard Drive Control is insensitive to inaccurate motor data settings 	<ul style="list-style-type: none"> • Typical settling time after a speed change: < 100 ms • Typical settling time after a sudden load change: 200 ms • Dynamic Drive Control controls and limits the motor torque • Typically achieves a torque accuracy: ± 5 % for 15 % ... 100 % of the rated speed • We recommend Dynamic Drive Control for the following applications: <ul style="list-style-type: none"> – Motor power ratings > 11 kW – On sudden load changes 10% ... >100% of the motor rated torque • Dynamic Drive Control is necessary for a ramp-up time 0 → rated speed (depending on the motor power rating): < 1 s (0.1 kW) ... < 10 s (18.5 kW). 
Max. output frequency	550 Hz	240 Hz
Commissioning	<ul style="list-style-type: none"> • Unlike "Dynamic Drive Control," no speed controller needs to be set • As compared with "configuration for experts": <ul style="list-style-type: none"> – Simplified commissioning using predefined motor data – Reduced number of parameters 	<ul style="list-style-type: none"> • Reduced number of parameters as compared with "configuration for experts"

4.2.2 Standard Drive Control

6.  Motor standard
 KW 50HZ IEC
 HP 60HZ NEMA
 KW 60HZ IEC 60 Hz
7.  Supply voltage for the inverter
8. Enter the motor data:
- 8.1.  Motor type
 Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.
 INDUCT Third-party induction motor
 SYNC Third-party synchronous motor
 RELUCT Third-party reluctance motor
 1L... IND 1LE1, 1LG6, 1LA7, 1LA9 induction motors
 1LE1 IND 1LE1□9 with motor code on the rating plate
 100
 1PC1 IND 1PC1 with motor code on the rating plate
 1PH8 IND Induction motor
 1FP1 Reluctance motor
 1F... SYN 1FG1, 1FK7 synchronous motor, without encoder
- 8.2.  If you have selected a motor type > 100, then you must enter the motor code:
 With the correct motor code, the inverter assigns the motor data the following values.
 If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.
- 8.3.  87 Hz motor operation
 The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).
- 8.4.  Rated voltage
- 8.5.  Rated current
- 8.6.  Rated power
- 8.7.  Rated frequency
- 8.8.  Rated speed

- 8.9. MOT COOL
P335 Motor cooling
 - SELF Natural cooling
 - FORCED Forced-air cooling
 - LIQUID Liquid cooling
 - NO FAN Without fan

 - 9. TEC APPL
P501 Select the application:
 - VEC STD Constant load: Typical applications include belt conveyor drives.
 - PUMP FAN Speed-dependent load: Typical applications include pumps and fans.

 - 10. MAc PAR
P15 Select the default setting for the interfaces of the inverter that is suitable for your application.
 - Default setting of the interfaces (Page 28)

 - 11. MIN RPM
P1080 Minimum and maximum motor speed
 - 12. MAX RPM
P1082
-
- 13. RAMP UP
P1120 Motor ramp-up time
 - 14. RAMP DWN
P1121 Motor ramp-down time
-
- 15. OFF3 RP
P1135 Ramp-down time for the OFF3 command

 - 16. MOT ID
P1900 Motor data identification

Select the method which the inverter uses to measure the data of the connected motor:


 - OFF Motor data is not measured.
 - STIL ROT Recommended setting: Measure the motor data at standstill and with the motor rotating. The inverter switches off the motor after the motor data identification has been completed.
 - STILL Measure the motor data at standstill. The inverter switches off the motor after the motor data identification has been completed.

Select this setting if the motor cannot freely rotate, e.g. for a mechanically limited traversing range.
 - ROT Measure the motor data while it is rotating. The inverter switches off the motor after the motor data identification has been completed.
 - ST RT OP Setting the same as STIL ROT.

After the motor data identification, the motor accelerates to the currently set setpoint.

STILL OP Setting the same as STILL.

After the motor data identification, the motor accelerates to the currently set setpoint.


17.  Complete quick commissioning:


17.1. Switchover the display using an arrow key: nO → YES

17.2. Press the OK key.


 You have completed quick commissioning.

4.2.3 Dynamic Drive Control

6.  Motor standard
 KW 50HZ IEC
 HP 60HZ NEMA
 KW 60HZ IEC 60 Hz

7.  Supply voltage for the inverter

8. Enter the motor data:





- 8.1.  Motor type
 Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.
- | | |
|-----------|---|
| INDUCT | Third-party induction motor |
| SYNC | Third-party synchronous motor |
| RELUCT | Third-party reluctance motor |
| 1L... IND | 1LE1, 1LG6, 1LA7, 1LA9 induction motors |
| 1LE1 IND | 1LE1□9 with motor code on the rating plate |
| 100 | |
| 1PC1 IND | 1PC1 with motor code on the rating plate |
| 1PH8 IND | Induction motor |
| 1FP1 | Reluctance motor |
| 1F... SYN | 1FG1, 1FK7 synchronous motor, without encoder |

- 8.2.  If you have selected a motor type > 100, then you must enter the motor code:

With the correct motor code, the inverter assigns the motor data the following values.

If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.

- 8.3.  87 Hz motor operation
 The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).

- 8.4.  Rated voltage
- 8.5.  Rated current
- 8.6.  Rated power
- 8.7.  Rated frequency
- 8.8.  Rated speed
- 8.9.  Motor cooling
 SELF Natural cooling
 FORCED Forced-air cooling
 LIQUID Liquid cooling
 NO FAN Without fan
- 9.  Select the application:
 OP LOOP Recommended setting for standard applications.
 CL LOOP Recommended setting for applications with short ramp-up and ramp-down times. This setting is not suitable for hoisting gear and cranes/lifting gear.
 HVY LOAD Recommended setting for applications with a high break loose torque.
- 10.  Select the default setting for the interfaces of the inverter that is suitable for your application.
 Default setting of the interfaces (Page 28)
- 11.  Minimum and maximum motor speed
- 12.  
- 13.  Motor ramp-up time
- 14.  Motor ramp-down time 
- 15.  Ramp-down time for the OFF3 command

16.  Motor data identification
- Select the method which the inverter uses to measure the data of the connected motor:
- OFF Motor data is not measured.
 - STIL ROT Recommended setting: Measure the motor data at standstill and with the motor rotating.
The inverter switches off the motor after the motor data identification has been completed.
 - STILL Measure the motor data at standstill.
The inverter switches off the motor after the motor data identification has been completed.
Select this setting if the motor cannot rotate freely – for example, if the traversing range is mechanically limited.
 - ROT Measure the motor data while it is rotating.
The inverter switches off the motor after the motor data identification has been completed.
 - ST RT OP Setting the same as STIL ROT.
The motor accelerates to the currently set setpoint after the motor data identification.
 - STILL OP Setting the same as STILL.
After the motor data identification, the motor accelerates to the currently set setpoint.
17.  Complete quick commissioning:
- 17.1. Switch over the display using an arrow key: nO → YES
 - 17.2. Press the OK key.
-  You have completed quick commissioning.

4.2.4 Identifying the motor data and optimizing the closed-loop control

The inverter has several techniques to automatically identify the motor data and optimize the speed control.

To start the motor data identification routine, you must switch-on the motor via the terminal strip, fieldbus or from the operator panel.

 WARNING
<p>Risk of death due to machine motion while motor data identification is active</p> <p>For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to its rated speed. Secure dangerous machine parts before starting motor data identification:</p> <ul style="list-style-type: none"> • Before switching on, ensure that nobody is working on the machine or located within its working area. • Secure the machine's work area against unintended access. • Lower hanging/suspended loads to the floor.

Preconditions

- You selected a method of motor data identification during quick commissioning, e.g. measurement of the motor data while the motor is stationary.



When quick commissioning is complete, the inverter issues alarm A07991.

- The motor has cooled down to the ambient temperature.

An excessively high motor temperature falsifies the motor data identification results.

Procedure when using the BOP-2 operator panel



To start the motor data identification, proceed as follows:


-  →  Press the HAND/AUTO key.
 ⇒ The BOP-2 displays the symbol for manual operation.
-  Switch on the motor.
-  During motor data identification, "MOT-ID" flashes on the BOP-2.
-  If the inverter again outputs alarm A07991, then it waits for a new ON command to start the rotating measurement.
 If the inverter does not output alarm A07991, proceed to step 7.
-  Switch on the motor to start the rotating measurement.
-  During motor data identification, "MOT-ID" flashes on the BOP-2.
 The motor data identification can take up to 2 minutes depending on the rated motor power.
-  Depending on the setting, after motor data identification has been completed, the inverter switches off the motor - or it accelerates it to the currently set setpoint.
 If required, switch off the motor.
-  Switch the inverter control from HAND to AUTO.



You have completed the motor data identification.

4.2.5 Additional settings

4.2.5.1 Operating the inverter with the BOP-2



1) Status display once the power supply for the inverter has been switched on.

Image 4-1 Menu of the BOP-2




Image 4-2 Other keys and symbols of the BOP-2

Procedure for switching the motor on and off via the operator panel:

1. Press MANUAL AUTO 
2. Master control of the inverter is released via the BOP-2 
3. Switch on motor 
4. Switch off the motor 

Changing settings using BOP-2

You can modify the settings of your inverter by changing the values of the its parameters. The inverter only permits changes to "write" parameters. Write parameters begin with a "P", e.g. P45.


The value of a read-only parameter cannot be changed. Read-only parameters begin with an "r", for example: r2.

Procedure



To change write parameters using the BOP-2, proceed as follows:

1. Select the menu to display and change parameters. Press the OK key.
2. Select the parameter filter using the arrow keys. Press the OK key.
 - STANDARD: The inverter only displays the most important parameters.
 - EXPERT: The inverter displays all of the parameters.
3. Select the required number of a write parameter using the arrow keys. Press the OK key.
4. Select the value of the write parameter using the arrow keys. Accept the value with the OK key.



■ You have now changed a write parameter using the BOP-2.

The inverter saves all the changes made using the BOP-2 so that they are protected against power failure.

Changing indexed parameters

For indexed parameters, several parameter values are assigned to a parameter number. Each of the parameter values has its own index.


Procedure



To change an indexed parameter, proceed as follows:

1. Select the parameter number.
2. Press the OK key.
3. Set the parameter index.
4. Press the OK key.
5. Set the parameter value for the selected index.

■ You have now changed an indexed parameter.



Directly select the parameter number

The BOP-2 offers the possibility of setting the parameter number digit by digit.

Precondition


The parameter number is flashing in the BOP-2 display.

Procedure



To select the parameter number directly, proceed as follows:

1. Press the OK button for longer than five seconds.
2. Change the parameter number digit-by-digit.
If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter number, press the OK button.



You have now entered the parameter number directly.

Entering the parameter value directly

The BOP-2 offers the option of setting the parameter value digit by digit.

Precondition


The parameter value flashes in the BOP-2 display.

Procedure



To select the parameter value directly, proceed as follows:


1. Press the OK button for longer than five seconds.
2. Change the parameter value digit-by-digit.
If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter value, press the OK button.




You have now entered the parameter value directly.

When must you not change a parameter?


The converter indicates why it currently does not permit a parameter to be changed:



You have attempted to change a read-only parameter.




You must change to quick commissioning to set this parameter.



You must turn the motor off to set this parameter.

The operating state in which you can change a parameter is provided in the List Manual for each parameter.

4.2.5.2 Changing the function of individual terminals



The function of the terminal is defined through a signal interconnection in the inverter:

- The inverter writes every input signal into a readable parameter. Parameter r0755 makes the signal of the analog input available, for example. To define the function of the input, the appropriate parameter (connector CI or BI) must be set to the parameter number of the input.
- Every inverter output is represented by a parameter that can be written to. The value of parameter p0771 defines the analog output signal, for example.

To define the output function, you must set the parameter number of the output to the parameter number of the matching signal (binector CO or BO).

In the parameter list, the abbreviation CI, CO, BI or BO as prefix indicates as to whether the parameter is available as signal for the function of the terminal.

Defining the function of a digital input

Procedure



To define the function of a digital input, proceed as follows:

1. Select the function marked using a BI parameter.
2. Enter the parameter number of the required digital input 722.x into the BI parameter.



You have defined the digital input function.

Example: You want to switch on the motor using DI 2.	Setting in BOP-2:

Advanced settings

When switching over the master control of the inverter (for example, if you select default setting 7), you must select the correct index of the parameter:

- Index 0 (e.g., P840[00]) applies for the interface assignment on the left side of the macro illustration.
- Index 1 (e.g., P840[01]) applies for the interface assignment on the right side of the macro illustration.

Defining the function of an analog input

Procedure

- ➔ 1 To define the function of an analog input, proceed as follows:
- 2
1. Select the function marked using a CI parameter.
 2. Enter the parameter number of analog input 755[00] into the CI parameter.
 3. Determine whether the analog input is a current or a voltage input:
 - Set the I/U switch at the front of the inverter to the correct position.
 - Set the p0756[00] parameter to the corresponding value.

■ You have now defined the analog input function.

Example: You want to enter the supplementary setpoint via AI 0.	Setting in BOP-2:

Advanced settings

When switching over the master control of the inverter (for example, if you select default setting 7), you must select the correct index of the parameter:

- Index 0 (e.g. p1075[00]) applies to the assignment for the interface on the left-hand side of the macro representation.
- Index 1 (e.g. P1075[01]) applies to the assignment for the interface on the right-hand side of the macro representation.

Defining the function of a digital output

Procedure

- ➔ 1 To define the function of a digital output, proceed as follows:
- 2
1. Select the function marked using a BO parameter.
 2. Enter the number of the BO parameter into parameter p073x of the digital output.

■ You have defined the digital output function.

Example: You want to report a "fault" signal via the DO 1.	Setting in BOP-2:

Defining the function of an analog output

Procedure



1 To define the function of an analog output, proceed as follows:

1. Select the function marked using a CO parameter.
2. Enter the number of the CO parameter into parameter p0771 of the analog output.
3. Use p0776[0] to determine whether the analog output is a current or voltage input.




You have now defined the analog output function.

Example: You want to output the signal for the actual current via AO 0.	Setting in BOP-2:				
	<table border="1"> <tr> <td>P771</td> <td>[00]</td> </tr> <tr> <td>r27</td> <td>[00]</td> </tr> </table>	P771	[00]	r27	[00]
P771	[00]				
r27	[00]				

4.2.5.3 Releasing the failsafe function "Safe Torque Off" (STO)

Precondition



You selected an interface assignment with terminals reserved for a failsafe function.



Default setting of the interfaces (Page 28).

Procedure



1 For releasing the STO function you have to set the following parameters:

1. p0010 = 95 - Enter commissioning of fail-safe functions.
2. p9761 = ... - Enter password for fail-safe function (factory setting = 0).
3. p9762 = ... - Enter new password, if required (0 ... FFFF FFFF).
4. p9763 = ... - Confirm new password.
5. p9601.0 = 1 - Select STO via terminal strip.
6. p9659 = ... - Set the forced checking procedure timer.
7. p9700 = D0 - Copy fail-safe parameters.
8. p9701 = DC - Confirm fail-safe parameters.
9. p0010 = 0 - Finish commissioning of fail-safe functions
10. p0971 = 1 - Save the parameters in a non-volatile memory
11. Wait until p0971 = 0
12. Bring the converter into a completely no-voltage condition (400V and 24V) and switch on again.



You have released the STO function.

4.2.5.4 Parameter list

The following list contains the basic parameter information with access level 1 ... 3. The complete parameter list is provided in the list manual.

 Overview of the manuals (Page 84)

No.	Description
Operation and visualization	
r0002	Drive operating display
p0003	Access level
p0010	Drive, commissioning parameter filter
p0015	Macro drive unit  Default setting of the interfaces (Page 28)
r0018	Control Unit firmware version
r0020	Speed setpoint smoothed [100 % \pm p2000]
r0021	CO: Actual speed smoothed [100 % \pm p2000]
r0022	Speed actual value rpm smoothed [rpm]
r0024	Output frequency smoothed [100 % \pm p2000]
r0025	CO: Output voltage smoothed [100 % \pm p2001]
r0026	CO: DC link voltage smoothed [100 % \pm p2001]
r0027	CO: Absolute actual current smoothed [100 % \pm p2002]
r0031	Actual torque smoothed [100 % \pm p2003]
r0032	CO: Active power actual value smoothed [100 % \pm r2004]
r0034	Motor utilization [100 \pm 100%]
r0035	CO: Motor temperature [100°C \pm p2006]
r0036	CO: Power unit overload I ² t [100 \pm 100%]
r0039	Energy consumption [kWh]
	[0] Energy balance (total) [1] Energy drawn
	[2] Energy fed back
p0040	0 \rightarrow 1 Reset the energy consumption display
r0041	Energy usage saved/energy saved
r0042	CO: Process energy display
	[0] Energy balance (total) [1] Energy drawn
	[2] Energy fed back
p0043	BI: Release display of energy consumption 0 \rightarrow 1: Start energy display r0042
p0045	Smoothing time constant, display values [ms]
r0046	CO/BO: Missing enable signals
r0047	Motor data identification routine and speed controller optimization
r0050	CO/BO: Command Data Set CDS effective

No.	Description
r0051	CO/BO: Drive Data Set DDS effective
r0052	CO/BO: Status word 1
	.00 Ready to start
	.01 Ready
	.02 Operation enabled
	.03 Fault active
	.04 Coast down active (OFF2)
	.05 Quick stop active (OFF3)
	.06 Closing lockout active
	.07 Alarm active
	.08 Deviation, setpoint/actual speed
	.09 Control requested
	.10 Maximum speed reached
	.11 I,M,P limit reached
	.12 Motor holding brake open
	.13 Alarm overtemperature motor
.14 Motor rotates forwards	
.15 Alarm inverter overload	
r0053	CO/BO: Status word 2
r0054	CO/BO: Control word 1
	.00 ON/OFF1
	.01 OFF2
	.02 OFF3
	.03 Enable ramp-function generator
	.04 Enable ramp-function generator
	.05 Continue ramp-function generator
	.06 Enable speed setpoint
	.07 Acknowledge fault
	.08 Jog bit 0
	.09 Jog bit 1
	.10 Master control by PLC
	.11 Direction reversal (setpoint)
	.13 Motorized potentiometer, raise
	.14 Motorized potentiometer, lower
.15 CDS bit 0	

No.	Description	
r0055	CO/BO: Supplementary control word	
	.00 Fixed setpoint, bit 0	
	.01 Fixed setpoint, bit 1	
	.02 Fixed setpoint, bit 2	
	.03 Fixed setpoint, bit 3	
	.04 DDS selection, bit 0	
	.05 DDS selection, bit 1	
	.08 Technology controller enable	
	.09 DC braking enable	
	.11 Droop enable	
	.12 Closed-loop torque control active	
	.13 External fault 1 (F07860)	
	.15 CDS bit 1	
	r0056	CO/BO: Status word, closed-loop control
	r0060	CO: Speed setpoint before setpoint filter [100 % ± p2000]
r0062	CO: Speed setpoint after filter [100 % ± p2000]	
r0063	CO: Speed actual value unsmoothed [100 % ± p2000]	
r0064	CO: Speed controller system deviation [100 % ± p2000]	
r0065	Slip frequency [100 % ± p2000]	
r0066	CO: Output frequency [100 % ± p2000]	
r0067	CO: Output current, maximum [100 % ± p2002]	
r0068	CO: Absolute current actual value unsmoothed [100 % ± p2002]	
r0070	CO: Actual DC link voltage [100 % ± p2001]	
r0071	Maximum output voltage [100 % ± p2001]	
r0072	CO: Output voltage [100 % ± p2001]	
r0075	CO: Current setpoint field-generating [100 % ± p2002]	
r0076	CO: Current actual value field-generating [100 % ± p2002]	
r0077	CO: Current setpoint torque-generating [100 % ± p2002]	
r0078	CO: Current actual value torque-generating [100 % ± p2002]	
r0079	CO: Torque setpoint, total [100 % ± p2003]	
r0080	CO: Actual torque value	
	[0] unsmoothed [1] smoothed	
r0082	CO: Active power actual value	
	[0] unsmoothed [1] smoothed with p0045	
	[2] Electric power	

No.	Description	
Commissioning		
p0096	Application class	
	0 Expert 1 Standard Drive Control 2 Dynamic Drive Control	
p0100	IEC/NEMA motor standard	
	0 IEC motor (50 Hz, SI units) 1 NEMA motor (60 Hz, US units) 2 NEMA motor (60 Hz, SI units)	
p0124	CU Identification via LED	
p0133	Motor configuration	
	.00 1: Delta 0: Star .01 1: 87 Hz 0: No 87 Hz	
p0170	Number of Command Data Sets (CDS)	
p0180	Number of Drive Data Sets (DDS)	
Power Module		
p0201	Power unit code number	
r0204	Power unit, hardware properties	
p0205	Power unit application	
	0 Load cycle with high overload 1 Load cycle with light overload	
r0206	Rated power unit power [kw/hp]	
r0207	Rated power unit current	
r0208	Rated power unit line supply voltage [V]	
r0209	Power unit, maximum current	
p0210	Drive unit line supply voltage [V]	
p0219	Braking resistor braking power [kW]	
p0230	Drive filter type, motor side	
	0 No filter 1 Motor reactor 2 dv/dt filter 3 Siemens sine-wave filter 4 Sine wave filter, third-party manufacturer	
	p0233	Power unit motor reactor [mH]
	p0234	Power unit sine-wave filter capacitance [µF]
r0238	Internal power unit resistance	
p0287	Ground fault monitoring thresholds [100 % ± r0209]	
r0289	CO: Maximum power unit output current [100 % ± p2002]	

No.	Description	No.	Description						
p0290	Power unit overload response	p0340	Automatic calculation of motor/control parameters						
0	Reduce output current or output frequency	p0341	Motor moment of inertia [kgm ²]						
1	No reduction, shutdown when overload threshold is reached	p0342	Ratio between the total and motor moment of inertia [kgm ²]						
2	Reduce I _{output} or f _{output} and f _{pulse} (not using I _{2t}).	p0344	Motor weight (for thermal motor model) [kg]						
3	Reduce the pulse frequency (not using I _{2t})	r0345	Motor rated running-up time [s]						
12	I _{output} or f _{output} and automatic pulse frequency reduction	p0346	Motor excitation build-up time [s]						
13	Automatic pulse frequency reduction	p0347	Motor de-excitation time [s]						
p0292	Power unit temperature alarm threshold [°C]	p0350	Motor stator resistance, cold [Ω]						
p0295	Fan run-on time [s]	p0352	Cable resistance [Ω]						
Motor		r0394	Rated motor power [kW]						
p0300	Motor type selection	r0395	Actual stator resistance						
0	No motor	1	Standard induction motor	2	Synchronous motor	Technology and units			
10	1LE1	13	1LG6	17	1LA7	p0500	Technology application		
19	1LA9	100	1LE1	101	1PC1	0	Standard drive	1	Pumps and fans
108	1PH8	271	1FG1	277	1FK7	2	Encoderless control up to f = 0	2	Pumps and fans, efficiency optimization
p0301	Motor code number selection	p0501		Technological application (Standard Drive Control)					
p0304	Rated motor voltage [V]	0	Constant load (linear characteristic)	1	Speed-dependent load (parabolic characteristic)				
p0305	Rated motor current [A]	p0502		Technology application (Dynamic Drive Control)					
p0306	Number of motors connected in parallel	0	Standard drive (e.g. pump, fan)	1	Dynamic approach or reversing				
p0307	Rated motor power [kW]	5	Heavy starting (e.g. extruders, compressors)	p0505		Selecting the system of units			
p0308	Rated motor power factor	1	SI	2	Referred/SI				
p0309	Rated motor efficiency [%]	3	US	4	Referred/US				
p0310	Rated motor frequency [Hz]	p0514		Specific scaling, reference values					
p0311	Rated motor speed [rpm]	p0515		Specific scaling, parameter referred to p0514[0]					
p0312	Rated motor torque [Nm]	p0516		Specific scaling, parameter referred to p0514[1]					
r0313	Motor pole pair number, current (or calculated)					
p0320	Motor rated magnetizing current/short-circuit current [A]	p0524		Specific scaling, parameter referred to p0514[9]					
p0322	Maximum motor speed [rpm]	p0530		Bearing, type selection					
p0323	Maximum motor current [A]	p0531		Bearing, code number selection					
p0325	Motor pole position identification current 1. Phase [A]	p0532		Bearing, maximum speed					
p0329	Motor pole position identification current [A]	p0541		Load gear unit code number					
r0330	Rated motor slip	p0542		Load gear unit maximum speed					
r0331	Actual motor magnetizing current/short-circuit current	p0543		Load gear unit maximum torque					
r0333	Rated motor torque [Nm]	p0544		Load gear unit gear ratio (absolute value) total, numerator					
p0335	Motor cooling type								

No.	Description	
p0545	Load gear unit gear ratio (absolute value) total, nominator	
p0546	Load gear unit output direction of rotation inversion	
p0550	Brake type	
p0551	Brake code number	
p0552	Brake maximum speed	
p0553	Brake holding torque	
p0554	Brake moment of inertia	
p0573	Inhibit automatic reference value calculation	
p0595	Selecting technological units	
	1 % 2 1 referred, dimensionless	
	3 bar 4 °C 5 Pa	
	6 ltr/s 7 m³/s 8 ltr/min	
	9 m³/min 10 ltr/h 11 m³/h	
	12 kg/s 13 kg/min 14 kg/h	
	15 t/min 16 t/h 17 N	
	18 kN 19 Nm 20 psi	
	21 °F 22 gallon/s 23 inch³/s	
	24 gallon/min 25 inch³/min 26 gallon/h	
	27 inch³/h 28 lb/s 29 lb/min	
	30 lb/h 31 lbf 32 lbf ft	
	33 K 34 rpm 35 parts/min	
	36 m/s 37 ft³/s 38 ft³/min	
	39 BTU/min 40 BTU/h 41 mbar	
	42 inch wg 43 ft wg 44 m wg	
	45 % r.h. 46 g/kg 47 ppm	
	p0596	Reference quantity, technological units
	Thermal motor monitoring and motor model, maximum current	
	p0601	Motor temperature sensor type
0 No sensor		
1 PTC warning & timer		
2 KTY84		
4 Bimetallic NC contact warning & timer		
6 PT1000		
p0604	Motor temperature alarm threshold [°C]	
p0605	Motor temperature fault threshold [°C]	

No.	Description
p0610	Motor overtemperature response
	0 No response, alarm only, no reduction of I _{max}
	1 Alarm with reduction of I _{max} and fault
	2 Alarm and fault, no reduction of I _{max}
12	Messages, no reduction of I _{max} , temperature is saved
p0611	I ² t motor model thermal time constant [s]
p0612	Motor temperature model activation
	.00 Activate motor temperature model 1 (I ² t) .01 Activate motor temperature model 2
	.02 Activate motor temperature model 3 .08 Activate motor temperature model 1 expansions
	.09 Activate motor temperature model 2 expansions .12 Motor temperature model 1 ambient temperature can be set
p0613	Motor temperature model 1/3 ambient temperature [°C]
p0614	Thermal resistor adaptation reduction factor
p0615	I ² t motor model fault threshold [°C]
p0625	Motor ambient temperature [°C]
p0637	Q flux, flux gradient saturated [mH]
p0640	Current limit [A]
p0650	Motor operating hours, current [h]
p0651	Motor operating hours, maintenance interval [h]
Command sources and terminals on the Control Unit	
r0720	CU number of inputs and outputs
r0722	CO/BO: CU digital inputs, status
	.00 DI 0 (terminal 5) .01 DI 1 (terminal 6)
	.02 DI 2 (terminal 7) .03 DI 3 (terminal 8)
	.04 DI 4 (terminal 16) .05 DI 5 (terminal 17)
	.11 DI 11 (terminals 3, 4) AI 0
r0723	CO/BO: CU digital inputs, status inverted
p0724	CU digital inputs debounce time [ms]
p0730	BI: CU signal source for terminal DO 0
	NO: Terminal 19 / NC: Terminal 18
p0731	BI: CU signal source for terminal DO 1
	NO: Terminal 21
r0747	CU, digital outputs status
p0748	CU, invert digital outputs
r0751	BO: CU analog inputs status word

No.	Description
r0752	CO: CU analog inputs input voltage/current actual AI0 (terminals 3/4)
p0753	CU analog inputs smoothing time constant [ms]
r0755	CO: CU analog inputs actual value in percent, AI0 (terminals 3/4) [100 ± 100%]
p0756	CU analog input type (terminals 3, 4)
	0 0 V ... +10 V 1 +2 V ... +10 V
	2 0 mA ... +20 mA 3 +4 mA ... +20 mA
	4 -10 V ... +10 V 8 No sensor connected
p0757	CU analog input characteristic value x1
p0758	CU analog input characteristic value y1 [%]
p0759	CU analog input characteristic value x2
p0760	CU analog input characteristic value y2 [%]
p0761	CU analog input wire break monitoring response threshold
p0762	CU analog inputs wire-break monitoring deceleration time [ms]
p0764	CU analog inputs deadband [V]
p0771	CI: CU analog output signal source, AO 0 (terminals 12, 13) [100 ± 100%]
r0772	CU analog output, output value currently referred
p0773	CU analog outputs smoothing time constant [ms]
r0774	CU analog output, output voltage/current actual [100% ± p2001]
p0775	CU analog output activate absolute value generation
p0776	CU analog output type
	0 0 mA ... +20 mA 1 0 V ... +10 V
	2 +4 mA ... +20 mA

No.	Description
p0777	CU analog output characteristic value x1 [%]
p0778	CU analog output characteristic value y1 [V]
p0779	CU analog output characteristic value x2 [%]
p0780	CU analog output characteristic value y2 [V]
p0782	BI: CU analog output invert signal source, AO 0 (terminals 12,13)
r0785	BO: CU analog outputs status word
	.00 1 = AO 0 negative
p0795	CU digital inputs, simulation mode
p0796	CU digital inputs, simulation mode setpoint
p0797	CU analog inputs, simulation mode
p0798	CU analog inputs, simulation mode setpoint
Change over and copy data sets	
p0802	Data transfer with memory card as source/target
p0803	Data transfer with device memory as source/target
p0804	Data transfer start
	12 Transfer GSD / GSDML for PROFIBUS / PROFINET onto the memory card
p0806	BI: Inhibit master control
r0807	BO: Master control active
p0809	Copy Command Data Set CDS
p0810	BI: Command data set selection CDS bit 0
p0819	Copy drive data set DDS
p0820	BI: Drive data set selection DDS, bit 0
p0826	Motor changeover, motor number
r0835	CO/BO: Data set changeover status word
r0836	CO/BO: Command data set CDS selected
r0837	CO/BO: Drive data set DDS selected
Sequential control system (e.g. ON/OFF1)	
p0840	BI: ON/OFF 1
p0844	BI: No coast down/coast down (OFF2) signal source 1
p0845	BI: No coast down/coast down (OFF2) signal source 2

No.	Description
p0848	BI: No quick stop/quick stop (OFF3) signal source 1
p0849	BI: No quick stop/quick stop (OFF3) signal source 1
p0852	BI: Enable operation
p0854	BI: Master control by PLC
p0855	BI: Unconditionally release holding brake
p0856	BI: Enable speed controller
p0857	Power Module monitoring time [ms]
p0858	BI: Unconditionally close holding brake
p0860	BI: Line contactor, feedback signal
p0861	Line contactor, monitoring time [ms]
r0863	CO/BO: Drive coupling status word / control word .00 1 = closed-loop control, operation .01 1 = operate line contactor
p0867	Power unit main contactor hold time after OFF1 [ms]
p0869	Configuration sequence control .00 1 = keep main contactor closed for STO
r0898	CO/BO: Control word sequence control
r0899	CO/BO: Status word sequence control
PROFIBUS, PROFIdrive	
p0918	PROFIBUS address
p0922	PROFIdrive telegram selection
1	Standard telegram 1, PZD-2/2
20	Standard telegram 20, PZD-2/6
352	SIEMENS telegram 352, PZD-6/6
353	SIEMENS telegram 353, PZD-2/2, PKW-4/4
354	SIEMENS telegram 354, PZD-6/6, PKW-4/4
999	Free telegram configuration with BICO
Faults (Part 1)	
r0944	CO: Counter for fault buffer changes
r0945	Fault code
r0946	Fault code list
r0947	Fault number
r0948	Fault time received in milliseconds [ms]
r0949	Fault value
p0952	Fault cases, counter
r0963	PROFIBUS baud rate
r0964	Device identification
p0965	PROFIdrive profile number

No.	Description
p0969	System runtime relative [ms]
Restoring the factory setting Saving parameters	
p0970	Reset drive parameters
0	Inactive 1 Reset parameters except for Safety
5	Reset safety parameters 10 Load setting 10
11	Load setting 11 12 Load setting 12
100	Reset BICO interconnections
p0971	Save parameters
0	Inactive
1	Save in nonvolatile storage (RAM → ROM)
10	Save in a non-volatile memory as setting 10
11	Save in a non-volatile memory as setting 11
12	Save in a non-volatile memory as setting 12
p0972	Drive unit reset
Setpoint channel	
p1000	Speed setpoint selection
p1001	CO: Fixed speed setpoint 1 [rpm]
p1002	CO: Fixed speed setpoint 2 [rpm]
...	...
p1015	CO: Fixed speed setpoint 15 [rpm]
p1016	Fixed speed setpoint mode
1	Direct selection 2 Selection, binary coded
p1020	BI: Fixed speed setpoint selection bit 0
p1021	BI: Fixed speed setpoint selection bit 1
p1022	BI: Fixed speed setpoint selection bit 2
p1023	BI: Fixed speed setpoint selection bit 3
r1024	CO: Fixed speed setpoint effective [100 % ± p2000]
r1025	BO: Fixed speed setpoint status .00 Fixed speed setpoint selected
p1030	Motorized potentiometer configuration
00	Storage active
01	Automatic operation, ramp-function generator active
02	Initial rounding active
03	Storage in NVRAM active
p1035	BI: Motorized potentiometer setpoint raise
p1036	BI: Motorized potentiometer setpoint lower
p1037	Motorized potentiometer maximum speed [rpm]

No.	Description
p1038	Motorized potentiometer minimum speed [rpm]
p1040	Motorized potentiometer start value [rpm]
p1043	Bl: Motorized potentiometer, accept setting value
p1044	Cl: Motorized potentiometer setting value [100 % \pm p2000]
r1045	CO: Motorized potentiometer, setpoint in front of the ramp-function generator [rpm]
p1047	Motorized potentiometer ramp-up time [s]
p1048	Motorized potentiometer ramp-down time [s]
r1050	CO: Motorized potentiometer setpoint after the ramp-function generator [100 % \pm p2000]
p1055	Bl: Jog bit 0
p1056	Bl: Jog bit 1
p1058	Jog 1 speed setpoint [rpm]
p1059	Jog 2 speed setpoint [rpm]
p1070	Cl: Main setpoint [100 % \pm p2000]
p1071	Cl: Main setpoint scaling [100 \pm 100%]
r1073	CO: Main setpoint effective [100 % \pm p2000]
p1075	Cl: Supplementary setpoint [100 % \pm p2000]
p1076	Cl: Supplementary setpoint scaling [100 \pm 100%]
r1077	CO: Supplementary setpoint effective [100 % \pm p2000]
r1078	CO: Total setpoint effective [100 % \pm p2000]
p1080	Minimum speed [rpm]
p1081	Maximum speed scaling [%]
p1082	Maximum speed [rpm]
p1083	CO: Speed limit in positive direction of rotation [rpm]
r1084	CO: Speed limit positive effective [100 % \pm p2000]
p1086	CO: Speed limit in negative direction of rotation [rpm]
r1087	CO: Speed limit negative effective [100 % \pm p2000]
p1091	Skip speed 1 [rpm]
p1092	Skip speed 2 [rpm]
p1101	Skip speed bandwidth [rpm]
p1106	Cl: Minimum speed signal source
p1110	Bl: Inhibit negative direction
p1111	Bl: Inhibit positive direction
p1113	Bl: Setpoint inversion
r1114	CO: Setpoint after the direction limiting [100 % \pm p2000]
r1119	CO: Ramp-function generator setpoint at the input [100 % \pm p2000]

No.	Description						
p1120	Ramp-function generator ramp-up time [s]						
p1121	Ramp-function generator ramp-down time [s]						
p1130	Ramp-function generator initial rounding-off time [s]						
p1131	Ramp-function generator final rounding-off time [s]						
p1134	Ramp-function generator rounding-off type						
	<table border="1"> <tr> <td>0</td> <td>Continuous smoothing</td> <td>1</td> <td>Discontinuous smoothing</td> </tr> </table>	0	Continuous smoothing	1	Discontinuous smoothing		
0	Continuous smoothing	1	Discontinuous smoothing				
p1135	OFF3 ramp-down time [s]						
p1136	OFF3 initial rounding-off time [s]						
p1137	OFF3 final rounding-off time [s]						
p1138	Cl: Acceleration ramp scaling [100 \pm 100%]						
p1139	Cl: Ramp down scaling [100 \pm 100%]						
p1140	Bl: Enable ramp-function generator						
p1141	Bl: Continue ramp-function generator						
p1142	Bl: Enable speed setpoint						
r1149	CO: Ramp-function generator acceleration [100 % \pm p2007]						
r1170	CO: Speed controller setpoint sum [100 % \pm p2000]						
r1198	CO/BO: Control word, setpoint channel						
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">Functions (e.g. motor holding brake)</div>							
p1200	Flying restart operating mode						
	<table border="1"> <tr> <td>0</td> <td>Flying restart inactive</td> </tr> <tr> <td>1</td> <td>Flying restart always active (start in setpoint direction)</td> </tr> <tr> <td>4</td> <td>Flying restart always active (start only in setpoint direction)</td> </tr> </table>	0	Flying restart inactive	1	Flying restart always active (start in setpoint direction)	4	Flying restart always active (start only in setpoint direction)
0	Flying restart inactive						
1	Flying restart always active (start in setpoint direction)						
4	Flying restart always active (start only in setpoint direction)						
p1201	Bl: Flying restart enable signal source						
p1202	Flying restart search current [100 % \pm r0331]						
p1203	Flying restart search rate factor [%]						
	A higher value results in a longer search time.						
p1206	Set fault number without automatic restart						

No.	Description
p1210	Automatic restart mode
	0 Inhibit automatic restart
	1 Acknowledge all faults without restarting
	4 Restart after line supply failure, without additional start attempts
	6 Restart after fault with additional start attempts
	14 Restart after line supply failure following manual acknowledgement
	16 Restart after fault following manual acknowledgement
	26 Acknowledging all faults and restarting for an ON command
p1211	Automatic restart, start attempts
p1212	Automatic restart, delay time start attempts [s]
p1213	Automatic restart, monitoring time [s]
	[0] Restart [1] Reset start counter
p1215	Motor holding brake configuration
	0 No motor holding brake being used
	3 Motor holding brake like sequential control, connection via BICO
p1216	Motor holding brake, opening time [ms]
p1217	Motor holding brake, closing time [ms]
p1226	Standstill detection threshold [rpm]
p1227	Standstill detection monitoring time [s]
p1230	BI: DC braking activation
p1231	DC braking configuration
	0 No function
	4 DC braking
	5 DC braking OFF1/OFF3
	14 DC braking below starting speed
p1232	DC braking, braking current [A]
p1233	DC braking time [s]
p1234	Speed at the start of DC braking [rpm]
r1239	CO/BO: DC braking status word
p1240	V _{DC} controller or V _{DC} monitoring configuration (vector control)
	0 Inhibit V _{DC} controller
	1 Enable V _{DC_max} controller
	2 Enable V _{DC_min} controller (kinetic buffering)
	3 Enable V _{DC_min} controller and V _{DC_max} controller
r1242	V _{DC_max} controller switch-in level [100 % ± p2001]
p1243	V _{DC_max} controller dynamic factor [%]

No.	Description
p1245	V _{DC_min} controller switch-in level (kinetic buffering) [%]
r1246	V _{DC_min} controller switch-in level (kinetic buffering) [100 % ± p2001]
p1247	V _{DC_min} controller dynamic factor (kinetic buffering) [%]
p1249	V _{DC_max} controller speed threshold [rpm]
p1250	V _{DC} controller proportional gain
p1251	V _{DC} controller integral time [ms]
p1252	V _{DC} controller rate time [ms]
p1254	V _{DC_max} controller automatic ON level detection
	0 Automatic detection inhibited
	1 Automatic detection enabled
p1255	V _{DC_min} controller time threshold [s]
p1256	V _{DC_min} controller response (kinetic buffering)
	0 Buffer V _{DC} until undervoltage, n<p1257 → F07405
	1 Buffer V _{DC} until undervoltage, n<p1257 → F07405, t>p1255 → F07406
p1257	V _{DC_min} controller speed threshold [rpm]
r1258	CO: V _{DC} controller output
p1271	Flying restart maximum frequency for the inhibited direction [Hz]
p1280	V _{DC} controller or V _{DC} monitoring configuration (V/f)
	0 Inhibit V _{DC} controller
	1 Enable V _{DC_max} controller
p1281	V _{DC} controller configuration
r1282	V _{DC_max} controller switch-in level (V/f) [100 % ± p2001]
p1283	V _{DC_max} controller dynamic factor (V/f) [%]
p1284	V _{DC_max} controller time threshold (U/f) [s]
p1288	V _{DC_max} controller ramp-function generator feedback factor (U/f)
p1290	V _{DC} controller proportional gain (U/f)
p1291	V _{DC} controller integral time (U/f) [ms]
p1292	V _{DC} controller rate time (U/f) [ms]
p1297	V _{DC_min} controller speed threshold (U/f) [rpm]

No.	Description
V/f control	
p1300	Open-loop/closed-loop control operating mode
0	V/f control with linear characteristic
1	V/f control with linear characteristic and FCC
2	V/f control with parabolic characteristic
3	V/f control with parameterizable characteristic
4	V/f control with linear characteristic and ECO
5	V/f control for drive requiring a precise frequency (e.g. textiles)
6	V/f control for drive requiring a precise frequency and FCC
7	V/f control for parabolic characteristic and ECO
19	V/f control with independent voltage setpoint
20	Speed control (without encoder)
p1302	V/f control configuration
p1310	Starting current (voltage boost) permanent [100 % ± p0305]
p1311	Starting current (voltage boost) acceleration [%]
p1312	Starting current (voltage boost) when starting [%]
r1315	Voltage boost, total [100 % ± p2001]

No.	Description
p1320	U/f control programmable frequency f [Hz] and voltage U [V] characteristic
...	
p1327	
p1330	CI: V/f control independent voltage setpoint [100 % ± p2001]
p1331	Voltage limiting [V]
p1333	U/f control FCC starting frequency [Hz]
p1334	V/f control slip compensation starting frequency [Hz]
p1335	Slip compensation, scaling [100 % ± r0330]
p1336	Slip compensation limit value [100 % ± r0330]
r1337	CO: Actual slip compensation [100 ± 100%]
p1338	V/f mode resonance damping gain
p1340	I_{max} frequency controller proportional gain
r1343	CO: I_{max} controller frequency output [100 % ± p2000]
p1349	U/f mode resonance damping maximum frequency [Hz]
p1351	CO: Motor holding brake starting frequency [100 ± 100%]
p1352	CI: Motor holding brake starting frequency [100 ± 100%]
Closed-loop speed control	
p1400	Speed control configuration
.00	1 = automatic Kp/Tn adaptation active
.01	1 = sensorless vector control, freeze I action
.05	1 = Kp/Tn adaptation active
.06	1 = free Tn adaptation active
.14	1 = torque precontrol is always active 0 = torque precontrol is active when speed controller enabled
.15	1 = sensorless vector control, speed precontrol active
.16	1 = release I action for limitation 0 = block I action for limitation
.18	1 = moment of inertia estimator active
.20	1 = acceleration model is switched on
.22	1 = obtain moment of inertia estimator value for pulse inhibit
.24	1 = moment of inertia estimator actively accelerates the motor
r1438	CO: Speed controller speed setpoint [100 % ± p2000]

No.	Description
p1452	Speed controller speed actual value smoothing time (SLVC) [ms]
p1470	Speed controller encoderless operation P gain
p1472	Speed controller sensorless operation integral time [ms]
p1475	CI: Speed controller torque setting value for motor holding brake [100 % ± p2003]
r1482	CO: Speed controller I torque output [100 % ± p2003]
r1493	CO: Total moment of inertia [kgm ²]
p1496	Acceleration pre-control scaling [%]
p1498	Load moment of inertia [kgm ²]
p1502	BI: Freezing the moment of inertia estimator 0 = moment of inertia estimator active 1 = determined moment of inertia is frozen
p1511	CI: Supplementary torque 1 [100 % ± p2003]
p1512	CI: Supplementary torque 1 scaling
r1516	CO: Supplementary torque and acceleration torque [100 % ± p2003]
p1520	CO: Torque limit upper [Nm]
p1521	CO: Torque limit lower [Nm]
p1522	CI: Torque limit upper [100 % ± p2003]
p1523	CI: Torque limit lower [100 % ± p2003]
p1524	CO: Torque limit upper/motoring scaling [100 ± 100%]
p1525	CO: Torque limit lower scaling [100 ± 100%]
r1526	CO: Torque limit upper without offset [100 % ± p2003]
r1527	CO: Torque limit lower without offset [100 % ± p2003]
p1530	Power limit motoring [kW]
p1531	Power limit regenerative [kW]
r1538	CO: Upper effective torque limit [100 % ± p2003]
r1539	CO: Lower effective torque limit [100 % ± p2003]
r1547	CO: Torque limit for speed controller output
	[0] Upper limit [100 % ± p2003]
	[1] Lower limit [100 % ± p2003]
p1552	CI: Torque limit upper scaling without offset [100 ± 100%]
p1554	CI: Torque limit lower scaling without offset [100 ± 100%]
p1560	Moment of inertia estimator, accelerating torque threshold value [100% ± r0333]
p1561	Moment of inertia estimator change time inertia [ms]

No.	Description	
p1562	Moment of inertia estimator change time load [ms]	
p1563	CO: Moment of inertia estimator load torque positive direction of rotation [Nm]	
p1564	CO: Moment of inertia estimator load torque negative direction of rotation [Nm]	
p1570	CO: Flux setpoint [100 ± 100%]	
p1580	Efficiency optimization [%]	
r1598	CO: Flux setpoint total [100 ± 100%]	
p1610	Torque setpoint static (SLVC) [100 % ± r0333]	
p1611	Supplementary accelerating torque (SLVC) [100 % ± r0333]	
p1616	Current setpoint smoothing time [ms]	
r1732	CO: Direct-axis voltage setpoint [100 % ± p2001]	
r1733	CO: Quadrature-axis voltage setpoint [100 % ± p2001]	
p1740	Gain resonance damping with sensorless control	
p1745	Motor model error threshold stall detection [%]	
p1750	Motor model configuration	
	.00	1 = forces open-loop speed-controlled starting
	.01	1 = forces open-loop-controlled crossing of frequency zero
	.02	1 = drive remains completely under closed-loop control even at frequency zero
	.03	1 = motor model evaluates saturation characteristic
	.06	1 = when motor is blocked, sensorless vector control remains under closed-loop speed control
	.07	1 = use of robust switchover limits for model switchover (open/closed-loop) during generating operation
p1755	Motor model changeover speed encoderless operation [rpm]	
p1780	Motor model adaptation configuration	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">Gating unit</div>		
p1800	Pulse frequency setpoint [kHz]	
r1801	CO: Pulse frequency [100 % ± p2000]	
p1806	Filter time constant V _{DC} correction [ms]	
p1810	Modulator configuration	
	.00	1 = averaging filter for voltage limiting
	.01	1 = DC link voltage compensation in current control

No.	Description
p1820	Reverse the output phase sequence 0 Off 1 On
r1838	CO/BO: Gating unit status word 1
Motor identification	
p1900	Motor data identification and rotating measurement 0 Inhibited 1 Identify the motor data at standstill and with the motor rotating 2 Identify motor data at standstill 3 Identify motor data with the motor rotating 11 Identify motor data and optimize the speed controller, operation 12 Identify motor data (at standstill), operation
p1901	Test pulse evaluation configuration
p1909	Motor data identification control word
p1910	Motor data identification selection
p1959	Rotating measurement configuration
p1960	Rotating measurement selection 0 Inhibited 1 Rotating measurement in encoderless operation 3 Speed controller optimization in encoderless operation
p1961	Saturation characteristic speed to determine [%]
p1965	Speed_ctrl_opt speed [100 % \pm p0310]
p1967	Speed_ctrl_opt dynamic factor [%]
p1980	PollID procedure 1 Voltage pulsing 1st harmonic 4 Voltage pulsing, 2-phase 6 Voltage pulsing, 2-phase inverse 8 Voltage pulsing 2nd harmonic, inverted 10 Impressing DC current
Reference values	
p2000	Reference speed reference frequency [rpm]
p2001	Reference voltage [V]
p2002	Reference current [A]
p2003	Reference torque [Nm]
r2004	Reference power
p2006	Reference temperature [°C]
p2010	Commissioning interface baud rate

No.	Description
p2011	Commissioning interface address
p2016	CI: Comm IF USS PZD send word
USS or Modbus RTU	
p2020	Fieldbus interface baud rate 4 2400 baud 5 4800 baud 6 9600 baud 7 19200 baud 8 38400 baud 9 57600 baud 10 76800 baud 11 93750 baud 12 115200 baud 13 187500 baud
p2021	Fieldbus interface address
p2022	Fieldbus interface USS PZD number
p2023	Fieldbus interface USS PKW number 0 PKW 0 words 3 PKW 3 words 4 PKW 4 words 127 PKW variable
p2024	Fieldbus interface times [ms] [0] Maximum processing time [1] Character delay time [2] Telegram pause time
r2029	Fieldbus interface error statistics [0] Number of error-free telegrams [1] Number of rejected telegrams [2] Number of framing errors [3] Number of overrun errors [4] Number of parity errors [5] Number of starting character errors [6] Number of checksum errors [7] Number of length errors
p2030	Fieldbus interface protocol selection 0 No protocol 1 USS 2 MODBUS 3 PROFIBUS 4 CAN 7 PROFINET 10 Ethernet/IP
p2031	Fieldbus interface Modbus parity 0 No parity 1 Odd parity 2 Even parity

No.	Description
r2032	Master control, control word effective
	.00 ON / OFF1
	.01 OFF2 inactive
	.02 OFF3 inactive
	.03 Enable operation
	.04 Enable ramp-function generator
	.05 Start ramp-function generator
	.06 Enable speed setpoint
	.07 Acknowledge fault
	.08 Jog bit 0
	.09 Jog bit 1
.10 Master control by PLC	
p2037	PROFIdrive STW1.10 = 0 mode
	0 Freeze setpoints and further process sign-of-life
	1 Freeze setpoints and sign-of-life
	2 Setpoints are not frozen
p2038	PROFIdrive STW/ZSW interface mode
	0 SINAMICS
	2 VIK-NAMUR
p2040	Fieldbus interface monitoring time [ms]
PROFIBUS, PROFIdrive	
p2042	PROFIBUS ID Number
	0 SINAMICS 2 VIK-NAMUR
r2043	BO: PROFIdrive PZD state
	.00 1 = setpoint failure .02 1 = fieldbus running
p2044	PROFIdrive fault delay [s]
p2047	PROFIBUS additional monitoring time [ms]
r2050	CO: PROFIdrive PZD receive word
	[0] PZD 1 ... [7] PZD 8
p2051	CI: PROFIdrive PZD send word
	[0] PZD 1 ... [7] PZD 8
r2053	PROFIdrive diagnostics send PZD word
	[0] PZD 1 ... [7] PZD 8
r2054	PROFIBUS status
	0 Off
	1 No connection (search for baud rate)
	2 Connection OK (baud rate found)
	3 Cyclic connection with master (data exchange)
4 Cyclic data OK	

No.	Description
r2055	PROFIBUS diagnosis standard
	[0] Master bus address
	[1] Master input total length bytes
[2] Master output total length bytes	
r2057	PROFIBUS address switch diagnostics
r2060	CO: IF1 PROFIdrive PZD receive double word
	[0] PZD 1 + 2 ... [10] PZD 11 + 12
r2061	CI: IF1 PROFIdrive PZD send double word
	[0] PZD 1 + 2 ... [10] PZD 11 + 12
r2063	IF1 PROFIdrive diagnostics PZD send double word
	[0] PZD 1 + 2 ... [10] PZD 11 + 12
r2067	IF1 PZD maximum interconnected
	[0] Receiving [1] Sending
p2072	Response, receive value after PZD failure
	.00 Unconditionally open holding brake (p0855) 1 = freeze value 0 = zero value
r2074	PROFIdrive diagnostics bus address PZD receive
	[0] PZD 1 ... [7] PZD 8
r2075	PROFIdrive diagnostics telegram offset PZD receive
	[0] PZD 1 ... [7] PZD 8
r2076	PROFIdrive diagnostics telegram offset PZD send
	[0] PZD 1 ... [7] PZD 8
r2077	PROFIBUS diagnostics peer-to-peer data transfer addresses
p2079	PROFIdrive PZD telegram selection extended See p0922
p2080	BI: Binector-connector converter, status word 1
	The individual bits are combined to form status word 1.
p2088	Binector-connector converter, invert status word
r2089	CO: Send binector-connector converter status word
	[0] Status word 1
	[1] Status word 2
	[2] Free status word 3
	[3] Free status word 4
[4] Free status word 5	
r2090	BO: PROFIdrive PZD1 receive bit-serial
r2091	BO: PROFIdrive PZD2 receive bit-serial
r2092	BO: PROFIdrive PZD3 receive bit-serial
r2093	BO: PROFIdrive PZD4 receive bit-serial

No.	Description	No.	Description
r2094	BO: Connector-binector converter binector output	p2165	Load monitoring blocking monitoring upper threshold [rpm]
r2095	BO: Connector-binector converter binector output	p2168	Load monitoring blocking monitoring torque threshold [Nm]
p2098	Invert connector-binector converter binector output	r2169	CO: Speed actual value smoothed signals [rpm]
p2099	CI: Connector-binector converter signal source	p2170	Current threshold value [A]
Faults (Part 2) and alarms		p2171	Current threshold value reached delay time [ms]
p2100	Setting the fault number for fault response	p2172	DC-link voltage threshold [V]
p2101	Setting the fault response	p2174	Torque threshold value 1 [Nm]
	0 None 1 OFF1	p2191	Load monitoring torque threshold without load [Nm]
	2 OFF2 3 OFF3	p2194	Torque threshold value 2 [%]
	5 STOP2 6 DC braking	p2195	Torque utilization switch-off delay [ms]
p2103	BI: 1. Acknowledge faults	r2197	CO/BO: Status word monitoring functions 1
p2104	BI: 2. Acknowledge faults	r2198	CO/BO: Status word monitoring 2
p2106	BI: External fault 1	r2199	CO/BO: Status word monitoring 3
r2110	Alarm number	Technology controller	
p2111	Alarm counter	p2200	BI: Technology controller enable
p2112	BI: External alarm 1	p2201	CO: Techn. controller fixed value 1 [100 ± 100%]
p2118	Change message type, message number	p2202	CO: Techn. controller fixed value 2 [100 ± 100%]
p2119	Change message type, type
	1 Fault 2 Alarm	p2215	CO: Techn. controller fixed value 15 [100 ± 100%]
	3 No message	p2216	Techn. controller fixed value selection method
r2122	Alarm code	0 Selection, direct 1 Selection, binary	
r2123	Alarm time received [ms]	p2220	BI: Techn. controller fixed value selection bit 0
r2124	Alarm value	p2221	BI: Techn. controller fixed value selection bit 1
r2125	Alarm time removed [ms]	p2222	BI: Techn. controller fixed value selection bit 2
p2126	Setting fault number for acknowledge mode	p2223	BI: Techn. controller fixed value selection bit 3
p2127	Sets acknowledgement mode	r2224	CO: Techn. controller fixed value active [100 ± 100%]
p2128	Selecting fault/alarm code for trigger	r2225	CO/BO: Techn. controller fixed value selection status word
r2129	CO/BO: Trigger word for faults and alarms	r2229	Techn. controller number currently
r2130	Fault time received in days	p2230	Techn. controller motorized potentiometer configuration
r2131	CO: Actual fault code		.00 Storage active
r2132	CO: Actual alarm code		.02 Initial rounding active
r2133	Fault value for float values		.03 Non-volatile data save active for p2230.0 = 1
r2134	Alarm value for float values		.04 Ramp-function generator always active
r2135	CO/BO: Status word faults / alarms 2	r2231	Techn. controller motorized potentiometer setpoint memory
r2136	Fault time removed in days	p2235	BI: Techn. controller motorized potentiometer setpoint up
r2138	CO/BO: Control word, faults/alarms		
r2139	CO/BO: Status word, faults/alarms 1		
p2141	Speed threshold value 1 [rpm]		
p2153	Speed actual value filter time constant [ms]		
p2155	Speed threshold value 2 [rpm]		
p2156	Switch-on delay comparison value reached [ms]		

No.	Description
p2236	BI: Techn. controller motorized potentiometer setpoint down
p2237	Techn. controller motorized potentiometer maximum value [%]
p2238	Techn. controller motorized potentiometer minimum value [%]
p2240	Techn. controller motorized potentiometer start value [%]
r2245	CO: Techn. controller motorized potentiometer setpoint before RFG [100 ± 100%]
p2247	Techn. controller motorized potentiometer ramp-up time [s]
p2248	Techn. controller motorized potentiometer ramp-down time [s]
r2250	CO: Techn. controller motorized potentiometer setpoint after RFG [100 ± 100%]
p2251	Techn. controller mode
	0 Techn. controller as main speed setpoint
	1 Techn. controller as additional speed setpoint
p2252	Technology controller configuration
	.04 1 = ramp function generator (up/down) bypass deactivated
	.05 1 = integrator for skip speeds active
	.06 1 = do not display internal controller limitation
p2253	CI: Techn. controller setpoint 1 [100 ± 100%]
p2254	CI: Techn. controller setpoint 2 [100 ± 100%]
p2255	Techn. controller setpoint 1 scaling [100 ± 100%]
p2256	Techn. controller setpoint 2 scaling [100 ± 100%]
p2257	Techn. controller ramp-up time [s]
p2258	Techn. controller ramp-down time [s]
r2260	CO: Techn. controller setpoint after ramp function generator [100 ± 100%]
p2261	Techn. controller setpoint filter time constant [s]
p2263	Techn. controller type
	0 D component in the actual value signal
	1 D component in the fault signal
p2264	CI: Techn. controller actual value [100 ± 100%]
p2265	Techn. controller actual value filter time constant [s]
r2266	CO: Techn. controller actual value after filter [100 ± 100%]
p2267	Techn. controller upper limit actual value [100 ± 100%]
p2268	Techn. controller lower limit actual value [100 ± 100%]

No.	Description
p2269	Techn. controller gain actual value [%]
p2270	Techn. controller actual value function selection
	0 No function 1 \sqrt{x}
	2 x^2 3 x^3
p2271	Techn. controller actual value inversion (sensor type)
	0 No inversion
	1 Inversion of the technology controller actual value signal
r2272	CO: Techn. controller actual value scaled [100 ± 100%]
r2273	CO: Techn. controller error [100 ± 100%]
p2274	Techn. controller actual differentiation time constant [s]
p2280	Techn. controller proportional gain
p2285	Techn. controller integral time [s]
p2286	BI: Hold techn. controller integrator
p2289	CI: Techn. controller pre-control signal [100 ± 100%]
p2290	BI: Technology controller limitation enable
	1 = enable technology controller output
p2291	CO: Techn. controller maximum limit [100 ± 100%]
p2292	CO: Techn. controller minimum limit [100 ± 100%]
p2293	Techn. controller ramp-up/ramp-down time [s]
r2294	CO: Techn. controller output signal [100 ± 100%]
p2295	CO: Techn. controller output scaling [100 ± 100%]
p2296	CI: Techn. controller output scaling [100 ± 100%]
p2297	CI: Techn. controller maximum limit signal source [100 ± 100%]
p2298	CI: Techn. controller minimum limit signal source [100 ± 100%]
p2299	CI: Techn. controller limit offset [100 ± 100%]
p2302	Techn. controller output signal start value [%]
p2306	Techn. controller fault signal inversion
	0 No inversion 1 Inversion of the fault signal
p2339	Techn. controller threshold value for I action stop at skip speed [%]
r2344	CO: Techn. controller last speed setpoint (smoothed) [100 ± 100%]
p2345	Techn. controller fault response
	0 Function inhibited
	1 For a fault: change over to r2344 (or p2302)
	2 For a fault: Change over to p2215
r2349	CO/BO: Techn. controller status word

No.	Description	No.	Description
p2350	PID Autotune Enable	r3333	CO/BO: 2-3 wire output
	0 No function		.00 2-3 wire ON
	1 Ziegler Nichols		.01 2-3 wire reverse
	2 Slight overshoot		3 No overshoot
	3 No overshoot		.02 2-3 wire ON / invert
	4 Optimize P and I action of the technology controller only		.03 2-3 wire reverse/invert
p2354	PID tuning timeout length	Friction characteristic	
p2355	PID tuning offset	p3820	Friction characteristic, value n0
p2900	CO: Fixed value 1 [100 ± 100%]	p3821	Friction characteristic, value n1
p2901	CO: Fixed value 2 [100 ± 100%]
r2902	CO: Fixed values [100 ± 100%]	p3829	Friction characteristic, value n9
p2930	CO: Fixed value M [Nm]	p3830	Friction characteristic, value M0
r2969	Direct axis flux model display	p3831	Friction characteristic, value M1
Messages	
r3113	CO/BO: NAMUR message bit bar	p3839	Friction characteristic, value M9
p3117	Change safety message type	r3840	CO/BO: Friction characteristic status word
	0 Safety messages are not reparameterized		.00 1 = Friction characteristic OK
	1 Safety messages are reparameterized		.01 1 = Recording of the friction characteristic activated
r3120	Component fault		.02 1 = Recording of the friction characteristic ended
	0 No assignment		.03 1 = Recording of the friction characteristic aborted
	1 Control Unit		.08 1 = Friction characteristic positive direction
	2 Power Module		
	3 Motor	r3841	CO: Friction characteristic, output [Nm]
r3121	Component alarm	p3842	Activate friction characteristic
	0 No assignment		1 Friction characteristic active
	1 Control Unit	p3845	Activate friction characteristic plot
	2 Power Module		0 Recording of friction characteristic plot deactivated
	3 Motor		1 Recording of friction characteristic in all directions
r3122	Diagnostic attribute fault		2 Recording of friction characteristic in positive direction only
r3123	Diagnostic attribute alarm		3 Recording of friction characteristic in negative direction only
p3233	Torque actual value filter time constant [ms]	p3846	Friction characteristic plot ramp-up/ramp-down time [s]
Energy-saving display		p3847	Friction characteristic plot warm-up period [s]
p3320	Fluid flow machine P = f(n), Y coordinate: P flow 1%, point 1	Compound braking	
p3321	Fluid flow machine P = f(n), X coordinate: n flow 1%, point 1	p3856	Compound braking current [100 ± 100%]
p3322	P = f(n), Y coordinate: P flow 2%, point 2	r3859	CO/BO: Compound braking status word
p3323	P = f(n), X coordinate: n flow 2%, point 2		
...	...		
p3328	P = f(n), Y coordinate: P flow 5%, point 5		
p3329	P = f(n), X coordinate: n flow 5%, point 5		
Two/three wire control			
p3330	BI: 2-3 wire control 1		
p3331	BI: 2-3 wire control 2		
p3332	BI: 2-3 wire control 3		

No.	Description	
Administration parameters		
p3900	Completion of quick commissioning	
r3925	Identification final display	
p3950	Service parameters	
p3981	Faults, acknowledge drive object	
p3985	Master control mode selection	
r3996	Parameter write inhibit status	
p5271	Online tuning controller configuration	
p5310	Moment of inertia precontrol configuration	
r5311	Moment of inertia precontrol status word	
p5312	Moment of inertia precontrol linear positive [s ²]	
p5313	Moment of inertia precontrol constant positive [kgms ²]	
p5314	Moment of inertia precontrol linear negative [s ²]	
p5315	Moment of inertia precontrol constant negative [kgms ²]	
p5316	Moment of inertia precontrol change time moment of inertia [ms]	
p5350	Mot_temp_mod 1/3 zero speed boost factor	
r5389	CO/BO: Mot_temp status word faults/alarms	
p5390	Mot_temp_mod 1/3 alarm threshold [°C]	
p5391	Mot_temp_mod 1/3 fault threshold [°C]	
p5397	Mot_temp_mod 3 ambient air temperature image p0613 [°C]	
r5398	Mot_temp_mod 3 alarm threshold image p5390 [°C]	
r5399	Mot_temp_mod 3 fault threshold image p5391 [°C]	
r5600	Pe hibernation ID	
p5602	Pe hibernation pause time, minimum [s]	
p5606	Pe hibernation duration, maximum [ms]	
p5611	Pe energy-saving properties, general	
	.00	Inhibit PROFlenergy .01 Drive triggers OFF1
p5611	Transition to hibernation from PROFIdrive state 4 possible	
	.02	Transition to hibernation from PROFIdrive state 4 possible
p5612	Pe energy-saving properties, mode-dependent	
r5613	CO/BO: Pe energy-saving active/inactive	
p5614	Bl: Set Pe Switching On Inhibited signal source	
r7758	Know-how protection Control Unit serial number	
r7759	Know-how protection Control Unit reference serial number	

No.	Description	
p7760	Write protection/know-how protection status	
	.00	1 = Write protection active
	.01	1 = Know-how protection active
	.02	1 = Know-how protection temporarily unlocked
	.03	1 = Know-how protection cannot be deactivated
	.04	1 = Memory card copy protection active
p7761	Write protection	
	0	Not active
p7762	Write access for control using multi-master third-party bus system	
	0	Free write access independent of p7761
p7763	Know-how protection OEM exception list number of parameters	
	1	No free write access (p7761 is active)
p7764	Know-how protection OEM exception list	
p7765	Know-how protection memory card copy protection	
	.00	1 = extended copy protection - linked to memory card and CU
	.01	1 = basic copy protection active - linked to memory card
p7766	Know-how protection password input	
	.02	1 = trace and measuring functions permitted for diagnostic purposes
p7767	Know-how protection password new	
p7768	Know-how protection password confirmation	
p7769	Know-how protection memory card setpoint serial number	
p7775	NVRAM data action	
r7843	Memory card serial number	
r8540	BO: STW1 from BOP/IOP in manual mode	
r8541	CO: Speed setpoint from BOP/IOP in manual mode	
p8542	Bl: Active STW1 in BOP/IOP manual mode	
p8543	Cl: Active speed setpoint in BOP/IOP manual mode	
p8552	IOP speed unit	
p8558	Bl: Selection IOP manual mode	
r8570	Macro Drive object Display of the macro files stored in the inverter. See also p0015.	

No.	Description	No.	Description
CANopen		p8731	CAN Transmit Mapping for TPDO 2 [hex]
r8600	CAN Device Type
r8601	CAN Error Register	p8737	CAN Transmit Mapping for TPDO 8 [hex]
p8602	CAN SYNC-Object	p8744	CAN PDO Mapping Configuration
p8603	CAN COB-ID Emergency Message [hex]	1:	Predefined connection set
p8604	CAN Node Guarding	2:	Free PDO mapping
p8606	CAN Producer Heartbeat Time [ms]	r8745	CO: CAN free PZD receive objects 16 bit
r8607	CAN Identity Object	p8746	CI: CAN free PZD send objects 16 bit
p8608	CAN Clear Bus Off Error	r8747	CO: CAN free PZD receive objects 32 bit
p8609	CAN Error Behavior	p8748	CI: CAN free PZD send objects 32 bit
r8610	CAN First Server SDO	r8750	CAN mapped receive objects 16 bit
p8611	CAN Pre-defined Error Field [hex]	r8751	CAN mapped receive objects 16 bit
p8620	CAN Node-ID	r8760	CAN mapped receive objects 32 bit
r8621	CAN Node-ID effective	r8761	CAN mapped transmit objects 32 bit
p8622	CAN bit rate [kBit/s]	r8762	CO: CAN operating mode display
	0 1000 1 800 2 500	r8784	CO: CAN status word
	3 250 4 125 5 50	p8785	BI: CAN status word bit 8
	6 20 7 10	p8786	BI: CAN status word bit 14
p8623	CAN Bit Timing selection [hex]	p8787	BI: CAN status word bit 15
p8630	CAN virtual objects	p8790	CAN control word - auto interconnection
p8641	CAN Abort Connection Option Code	p8791	CAN holding option code
	0 No response 1 OFF1	r8792	CO: CAN Velocity Mode I16 setpoint
	2 OFF2 3 OFF3	r8795	CAN control word
r8680	CAN Diagnosis Hardware	r8796	CO: CAN Profile Velocity Mode I32 setpoints
p8684	CAN NMT state after booting	r8797	CAN Target Torque
p8685	CAN NMT state	p8798	CAN speed conversion factor
p8699	CAN RPDO monitoring time [ms]	[0] Counters [1] Denominator	
p8700	CAN Receive PDO 1 [hex]	Identification & maintenance data (I&M)	
p8701	CAN Receive PDO 2 [hex]	p8805	Identification and Maintenance 4 configuration
...	...	0:	Standard value for I&M 4 (p8809)
p8707	CAN Receive PDO 8 [hex]	1:	User value for I&M 4 (p8809)
p8710	CAN Receive Mapping for RPDO 1 [hex]	p8806	Identification and Maintenance 1
p8711	CAN Receive Mapping for RPDO 2 [hex]	[0...31]	Plant ID (PID)
...	...	[32...53]	Location ID (LID)
p8717	CAN Receive Mapping for RPDO 8 [hex]	p8807	Identification and Maintenance 2
p8720	CAN Transmit PDO 1 [hex]	[0...15]	YYY-MM-DD hh.mm
p8721	CAN Transmit PDO 2 [hex]	p8808	Identification and Maintenance 3
...	...	[0...53]	Arbitrary supplementary information and remarks (ASCII)
p8727	CAN Transmit PDO 8 [hex]	p8809	Identification and Maintenance 4 (signature)
p8730	CAN Transmit Mapping for TPDO 1 [hex]		

No.	Description
PROFIdrive	
r8859	PROFINET identification data
r8909	PN Device ID
p8920	PN Name of station
p8921	PN IP Address of Station
p8922	PN Default Gateway of Station
p8923	PN Subnet Mask of Station
p8924	PN DHCP mode
p8925	PN interfaces configuration
	0: No function
	1: Activate the configuration
	2: Activate the configuration and save
p8929	PN Remote Controller number
	0: Automation or Safety 1: Automation and Safety
r8930	PN Name of Station active
r8931	PN IP Address of Station active
r8932	PN Default Gateway of Station active
r8933	PN Subnet Mask of Station active
r8934	PN DHCP mode active
r8935	PN MAC Address of Station
r8939	PN DAP ID
r8960	PN Subslot assignment
r8961	PN IP Addr Remote Controller 1
r8962	PN IP Addr Remote Controller 2
p8980	Ethernet/IP profile
	0: SINAMICS 1: ODVA / AC/DC
p8981	Ethernet/IP ODVA STOP mode
	0: OFF1 1: OFF2
p8982 p8983	Ethernet/IP ODVA speed (p8982) or torque (p8983) scaling
	123: 32 124: 16
	125: 8 126: 4
	127: 2 128: 1
	129: 0.5 130: 0.25
	131: 0.125 132: 0.0625
p8991	USB memory access

No.	Description
Parameter consistency and storage	
p9400	Safely remove memory card
	0 No memory card inserted
	1 Memory card inserted
	2 Request "safe removal" of the memory card
	3 "Safe removal" possible
100 "Safe removal" not possible due to access	
r9401	Safely remove memory card status
r9463	Set valid macro
p9484	BICO interconnections, search signal source
r9485	BICO interconnections, search signal source number
r9486	BICO interconnections, search signal source first index
Safety Integrated	
p9601	SI enable, functions integrated in the drive (processor 1)
p9610	SI PROFIsafe address (processor 1)
p9650	SI F-DI changeover, tolerance time (processor 1) [ms]
p9651	SI STO debounce time (processor 1) [ms]
p9659	SI forced checking procedure timer [h]
r9660	SI forced checking procedure remaining time [h]
r9670	SI module identifier, Control Unit
r9672	SI module identifier, Power Module
p9700	SI copy function
p9701	Acknowledge SI data change
p9761	SI password input [hex]
p9762	SI password new [hex]
p9763	SI password acknowledgment [hex]
r9768	SI PROFIsafe control words received (processor 1)
	[0] PZD 1 ... [7] PZD 8
r9769	SI PROFIsafe status words send (processor 1)
	[0] PZD 1 ... [7] PZD 8
r9770	SI version, safety functions integrated in the drive (processor 1)
r9771	SI common functions (processor 1)
r9772	CO/BO: SI status (processor 1)
r9773	CO/BO: SI status (processor 1 + processor 2)

No.	Description			
r9776	SI diagnostics			
	.00	1 = safety parameters changed, POWER ON required		
	.01	1 = safety functions enabled		
	.02	1 = safety components exchanged and save necessary		
r9780	SI monitoring clock cycle (processor 1) [ms]			
r9781	SI checksum to check changes (processor 1)			
r9782	SI time stamp to check changes (processor 1) [h]			
r9794	SI crosswise comparison list (processor 1)			
r9795	SI diagnostics, STOP F (processor 1)			
r9798	SI actual checksum SI parameters (processor 1)			
p9799	SI reference checksum SI parameters (processor 1)			
p9801	SI enable, functions integrated in the drive (processor 2)			
p9810	SI PROFIsafe address (processor 2)			
p9850	SI F-DI changeover, tolerance time (processor 2)			
p9851	SI STO debounce time (processor 2) [μs]			
r9871	SI common functions (processor 2)			
r9872	CO/BO: SI status (Power Module)			
r9898	SI actual checksum SI parameters (processor 2)			
p9899	SI reference checksum SI parameters (processor 2)			
Diagnostics (internal)				
r9976	System utilization [%]			
	[1]	Computation time utilization	[5]	Highest gross utilization
Free function blocks				
r20001	Runtime group sampling time [ms]			
	[0]	Runtime group 0 ...	[9]	Runtime group 9
p20030	BI: AND 0 inputs			
	[0]	Input I0 ...	[3]	Input I3
r20031	BO: AND 0 output Q			
p20032	AND 0 runtime group			
	1	Runtime group 1 ...	6	Runtime group 6
	9999	Not calculated		
p20033	AND 0 run sequence			
p20034	BI: AND 1 inputs → same as p20030			
r20035	BO: AND 1 output Q			
p20036	AND 1 runtime group → same as p20032			
p20037	AND 1 run sequence			
p20038	BI: AND 2 inputs → same as p20030			
r20039	BO: AND 2 output Q			
p20040	AND 2 runtime group → same as p20032			
p20041	AND 2 run sequence			
p20042	BI: AND 3 inputs → same as p20030			
r20043	BO: AND 3 output Q			
p20044	AND 3 runtime group → same as p20032			
p20045	AND 3 run sequence			
p20046	BI: OR 0 inputs → same as p20030			
r20047	BO: OR 0 output Q			
p20048	OR 0 runtime group → same as p20032			
p20049	OR 0 run sequence			
p20050	BI: OR 1 inputs → same as p20030			
r20051	BO: OR 1 output Q			
p20052	OR 1 runtime group → same as p20032			
p20053	OR 1 run sequence			
p20054	BI: OR 2 inputs → same as p20030			
r20055	BO: OR 2 output Q			
p20056	OR 2 runtime group → same as p20032			
p20057	OR 2 run sequence			
p20058	BI: OR 3 inputs → same as p20030			
r20059	BO: OR 3 output Q			
p20060	OR 3 runtime group → same as p20032			
p20061	OR 3 run sequence			
p20062	BI: XOR 0 inputs → same as p20030			
r20063	BO: XOR 0 output Q			
p20064	XOR 0 runtime group → same as p20032			
p20065	XOR 0 run sequence			
p20066	BI: XOR 1 inputs → same as p20030			
r20067	BO: XOR 1 output Q			
p20068	XOR 1 runtime group → same as p20032			
p20069	XOR 1 run sequence			
p20070	BI: XOR 2 inputs → same as p20030			
r20071	BO: XOR 2 output Q			
p20072	XOR 2 runtime group → same as p20032			
p20073	XOR 2 run sequence			
p20074	BI: XOR 3 inputs → same as p20030			
r20075	BO: XOR 3 output Q			
p20076	XOR 3 runtime group → same as p20032			
p20077	XOR 3 run sequence			
p20078	BI: NOT 0 input I			
r20079	BO: NOT 0 inverted output			

No.	Description
p20080	NOT 0 runtime group → same as p20032
p20081	NOT 0 run sequence
p20082	BI: NOT 1 input I
r20083	BO: NOT 1 inverted output
p20084	NOT 1 runtime group → same as p20032
p20085	NOT 1 run sequence
p20086	BI: NOT 2 input I
r20087	BO: NOT 2 inverted output
p20088	NOT 2 runtime group → same as p20032
p20089	NOT 2 run sequence
p20090	BI: NOT 3 input I
r20091	BO: NOT 3 inverted output
p20092	NOT 3 runtime group → same as p20032
p20093	NOT 3 run sequence
p20094	CI: ADD 0 inputs
	[0] Input X0 ... [3] Input X3
r20095	CO: ADD 0 output $Y = X0 + X1 + X2 + X3$
p20096	ADD 0 runtime group
	5 Runtime group 5 6 Runtime group 6
	9999 Not calculated
p20097	ADD 0 run sequence
p20098	CI: ADD 1 inputs → same as p20094
r20099	CO: ADD 1 output Y
p20100	ADD 1 runtime group → same as p20096
p20101	ADD 1 run sequence
p20102	CI: SUB 0 inputs
	[0] X1 [1] X2
r20103	CO: SUB 0 difference $Y = X1 - X2$
p20104	SUB 0 runtime group → same as p20096
p20105	SUB 0 run sequence
p20106	CI: SUB 1 inputs → same as p20102
r20107	CO: SUB 1 difference $Y = X1 - X2$
p20108	SUB 1 runtime group → same as p20096
p20109	SUB 1 run sequence
p20110	CI: MUL 0 inputs
	[0] Factor X0 ... [3] Factor X3
r20111	CO: MUL 0 product $Y = X0 \times X1 \times X2 \times X3$
p20112	MUL 0 runtime group → same as p20096
p20113	MUL 0 run sequence
p20114	CI: MUL 1 inputs → same as p20110
r20115	CO: MUL 1 product $Y = X0 \times X1 \times X2 \times X3$
p20116	MUL 1 runtime group → same as p20096

No.	Description
p20117	MUL 1 run sequence
p20118	CI: DIV 0 inputs
	[0] Dividend X0 [1] Divisor X1
r20119	CO: DIV 0 quotient
	[0] $Y = X0 / X1$ [1] Integer quotient YIN
	[2] Division remainder $MOD = (Y - YIN) \times X0$
r20120	BO: DIV 0 divisor is zero QF
p20121	DIV 0 runtime group → same as p20096
p20122	DIV 0 run sequence
p20123	CI: DIV 1 inputs → same as p20118
r20124	CO: DIV 1 quotient → same as p20119
r20125	BO: DIV 1 divisor is zero QF
p20126	DIV 1 runtime group → same as p20096
p20127	DIV 1 run sequence
p20128	CI: AVA 0 input X
r20129	CO: AVA 0 output $Y = IXI$
r20130	BO: AVA 0 input negative SN ($X < 0 \Rightarrow SN = 1$)
p20131	AVA 0 runtime group → same as p20096
p20132	AVA 0 run sequence
p20133	CI: AVA 1 input X
r20134	CO: AVA 1 output $Y = IXI$
r20135	BO: AVA 1 input negative S ($X < 0 \Rightarrow SN = 1$)
p20136	AVA 1 runtime group → same as p20096
p20137	AVA 1 run sequence
p20138	BI: MFP 0 input pulse I
p20139	MFP 0 pulse duration [ms]
r20140	BO: MFP 0 output Q
p20141	MFP 0 runtime group → same as p20096
p20142	MFP 0 run sequence
p20143	BI: MFP 1 input pulse
p20144	MFP 1 pulse duration [ms]
r20145	BO: MFP 1 output Q
p20146	MFP 1 runtime group → same as p20096
p20147	MFP 1 run sequence
p20148	BI: PCL 0 input pulse I
p20149	PCL 0 pulse duration [ms]
r20150	BO: PCL 0 output Q
p20151	PCL 0 runtime group → same as p20096
p20152	PCL 0 run sequence
p20153	BI: PCL 1 input pulse I
p20154	PCL 1 pulse duration [ms]
r20155	BO: PCL 1 output Q

No.	Description	No.	Description
p20156	PCL 1 runtime group → same as p20096	p20196	RSR 1 runtime group → same as p20032
p20157	PCL 1 run sequence	p20197	RSR 1 run sequence
p20158	BI: PDE 0 input pulse I	p20198	BI: DFR 0 inputs
p20159	PDE 0 pulse delay time [ms]		[0] Trigger input I [1] D input D
r20160	BO: PDE 0 output Q		[2] Set S [3] Reset R
p20161	PDE 0 runtime group → same as p20096	r20199	BO: DFR 0 output Q
p20162	PDE 0 run sequence	r20200	BO: DFR 0 inverted output QN
p20163	BI: PDE 1 input pulse I	p20201	DFR 0 runtime group → same as p20032
p20164	PDE 1 pulse delay time [ms]	p20202	DFR 0 run sequence
r20165	BO: PDE 1 output Q	p20203	BI: DFR 1 inputs → same as p20198
p20166	PDE 1 runtime group → same as p20096	r20204	BO: DFR 1 output Q
p20167	PDE 1 run sequence	r20205	BO: DFR 1 inverted output QN
p20168	BI: PDF 0 input pulse I	p20206	DFR 1 runtime group → same as p20032
p20169	PDF 0 pulse delay time [ms]	p20207	DFR 1 run sequence
r20170	BO: PDF 0 output Q	p20208	BI: BSW 0 inputs
p20171	PDF 0 runtime group → same as p20096		[0] Input I0 [1] Input I1
p20172	PDF 0 run sequence	p20209	BI: BSW 0 switch position I
p20173	BI: PDF 1 input pulse I	r20210	BO: BSW 0 output Q
p20174	PDF 1 pulse delay time [ms]	p20211	BSW 0 runtime group → same as p20032
r20175	BO: PDF 1 output Q	p20212	BSW 0 run sequence
p20176	PDF 1 runtime group → same as p20096	p20213	BI: BSW 1 inputs → same as p20208
p20177	PDF 1 run sequence	p20214	BI: BSW 1 switch position I
p20178	BI: PST 0 inputs	r20215	BO: BSW 1 output Q
	[0] Input pulse I [1] Reset input R	p20216	BSW 1 runtime group → same as p20032
p20179	PST 0 pulse duration [ms]	p20217	BSW 1 run sequence
r20180	BO: PST 0 output Q	p20218	CI: NSW 0 inputs
p20181	PST 0 runtime group → same as p20096		[0] Input X0 [1] Input X1
p20182	PST 0 run sequence	p20219	BI: NSW 0 switch position I
p20183	BI: PST 1 inputs → same as p20178	r20220	CO: NSW 0 output Y
p20184	PST 1 pulse duration [ms]	p20221	NSW 0 runtime group → same as p20096
r20185	BO: PST 1 output Q	p20222	NSW 0 run sequence
p20186	PST 1 runtime group → same as p20096	p20223	CI: NSW 1 inputs → same as p20218
p20187	PST 1 run sequence	p20224	BI: NSW 1 switch position I
p20188	BI: RSR 0 inputs	r20225	CO: NSW 1 output Y
	[0] Set S [1] Reset R	p20226	NSW 1 runtime group → same as p20096
r20189	BO: RSR 0 output Q	p20227	NSW 1 run sequence
r20190	BO: RSR 0 inverted output QN	p20228	CI: LIM 0 input X
p20191	RSR 0 runtime group → same as p20032	p20229	LIM 0 upper limit value LU
p20192	RSR 0 run sequence	p20230	LIM 0 lower limit value LL
p20193	BI: RSR 1 inputs → same as p20188	r20231	CO: LIM 0 output Y
r20194	BO: RSR 1 output Q	r20232	BO: LIM 0 input variable at the upper limit QU
r20195	BO: RSR 1 inverted output QN	r20233	BO: LIM 0 input variable at the lower limit QL

No.	Description
p20234	LIM 0 runtime group → same as p20096
p20235	LIM 0 run sequence
p20236	CI: LIM 1 input X
p20237	LIM 1 upper limit value LU
p20238	LIM 1 lower limit value LL
r20239	CO: LIM 1 output Y
r20240	BO: LIM 1 input variable at the upper limit QU
r20241	BO: LIM 1 input variable at the lower limit QL
p20242	LIM 1 runtime group → same as p20096
p20243	LIM 1 run sequence
p20244	CI: PT1 0 inputs [0] Input x [1] Setting value SV
p20245	BI: PT1 0 accept setting value S
p20246	PT1 0 smoothing time constant [ms]
r20247	CO: PT1 0 output Y
p20248	PT1 0 runtime group → same as p20096
p20249	PT1 0 run sequence
p20250	CI: PT1 1 inputs → same as p20244
p20251	BI: PT1 1 accept setting value S
p20252	PT1 1 smoothing time constant [ms]
r20253	CO: PT1 1 output Y
p20254	PT1 1 runtime group → same as p20096
p20255	PT1 1 run sequence
p20256	CI: INT 0 inputs → same as p20244
p20257	INT 0 upper limit value LU
p20258	INT 0 lower limit value LL
p20259	INT 0 integrating time constant [ms]
p20260	BI: INT 0 accept setting value S
r20261	CO: INT 0 output Y
r20262	BO: INT 0 integrator at the upper limit QU
r20263	BO: INT 0 integrator at the lower limit QL
p20264	INT 0 runtime group → same as p20096
p20265	INT 0 run sequence
p20266	CI: LVM 0 input X
p20267	LVM 0 interval mean value M
p20268	LVM 0 interval limit L
p20269	LVM 0 hysteresis HY
r20270	BO: LVM 0 input variable above interval QU
r20271	BO: LVM 0 input variable within interval QM
r20272	BO: LVM 0 input variable below interval QL
p20273	LVM 0 runtime group → same as p20096
p20274	LVM 0 run sequence

No.	Description
p20275	CI: LVM 1 input X
p20276	LVM 1 interval mean value M
p20277	LVM 1 interval limit L
p20278	LVM 1 hysteresis HY
r20279	BO: LVM 1 input variable above interval QU
r20280	BO: LVM 1 input variable within interval QM
r20281	BO: LVM 1 input variable below interval QL
p20282	LVM 1 runtime group → same as p20096
p20283	LVM 1 run sequence
p20284	CI: DIF 0 input X
p20285	DIF 0 differential time constant [ms]
r20286	CO: DIF 0 output Y
p20287	DIF 0 runtime group → same as p20096
p20288	DIF 0 run sequence
p20300	BI: NOT 4 input I
r20301	BO: NOT 4 inverted output
p20302	NOT 4 runtime group → same as p20032
p20303	NOT 4 run sequence
p20304	BI: NOT 5 input I
r20305	BO: NOT 5 inverted output
p20306	NOT 5 runtime group → same as p20032
p20307	NOT 5 run sequence
p20308	CI: ADD 2 inputs → same as p20094
r20309	CO: ADD 2 output Y
p20310	ADD 2 runtime group → same as p20096
p20311	ADD 2 run sequence
p20312	CI: NCM 0 inputs [0] Input X0 [1] Input X1
r20313	BO: NCM 0 output QU (QU = 1 if X0 > X1)
r20314	BO: NCM 0 output QE (QE = 1 if X0 = X1)
r20315	BO: NCM 0 output QL (QL = 1 if X0 < X1)
p20316	NCM 0 runtime group → same as p20096
p20317	NCM 0 run sequence
p20318	CI: NCM 1 inputs [0] Input X0 [1] Input X1
r20319	BO: NCM 1 output QU (QU = 1 if X0 > X1)
r20320	BO: NCM 1 output QE (QE = 1 if X0 = X1)
r20321	BO: NCM 1 output QL (QL = 1 if X0 < X1)
p20322	NCM 1 runtime group → same as p20096
p20323	NCM 1 run sequence
p20324	BI: RSR 2 inputs [0] Set S [1] Reset R

No.	Description
r20325	BO: RSR 2 output Q
r20326	BO: RSR 2 inverted output QN
p20327	RSR 2 runtime group → same as p20032
p20328	RSR 2 run sequence
p20329	BI: DFR 2 inputs → same as p20198
r20330	BO: DFR 2 output Q
r20331	BO: DFR 2 inverted output QN
p20332	DFR 2 runtime group → same as p20032
p20333	DFR 2 run sequence
p20334	BI: PDE 2 input pulse I
p20335	PDE 2 pulse delay time [ms]
r20336	BO: PDE 2 output Q
p20337	PDE 2 runtime group → same as p20096
p20338	PDE 2 run sequence
p20339	BI: PDE 3 input pulse I
p20340	PDE 3 pulse delay time [ms]
r20341	BO: PDE 3 output Q
p20342	PDE 3 runtime group → same as p20096
p20343	PDE 3 run sequence
p20344	BI: PDF 2 input pulse I
p20345	PDF 2 pulse delay time [ms]
r20346	BO: PDF 2 output Q
p20347	PDF 2 runtime group → same as p20096
p20348	PDF 2 run sequence
p20349	BI: PDF 3 input pulse I
p20350	PDF 3 pulse delay time [ms]
r20351	BO: PDF 3 output Q
p20352	PDF 3 runtime group → same as p20096
p20353	PDF 3 run sequence
p20354	BI: MFP 2 input pulse
p20355	MFP 2 pulse duration [ms]
r20356	BO: MFP 2 output Q
p20357	MFP 2 runtime group → same as p20096
p20358	MFP 2 run sequence
p20359	BI: MFP 3 input pulse
p20360	MFP 3 pulse duration [ms]
r20361	BO: MFP 3 output Q
p20362	MFP 3 runtime group → same as p20096
p20363	MFP 3 run sequence
p20372	CI: PLI 0 input X
r20373	CO: PLI 0 output Y
p20374	PLI 0 X coordinate A transition point

No.	Description			
	[0]	Transition point 0 ...	[19]	Transition point 19
p20375	PLI 0 Y coordinate B transition point			
	[0]	Transition point 0 ...	[19]	Transition point 19
p20376	PLI 0 runtime group → same as p20096			
p20377	PLI 0 run sequence			
p20378	CI: PLI 1 input X			
r20379	CO: PLI 1 output Y			
p20380	PLI 1 X coordinate A transition point → same as p 20374			
p20381	PLI 1 Y coordinate B transition point → same as p 20375			
p20382	PLI 1 runtime group → same as p20096			
p20383	PLI 1 run sequence			
p60022	Selecting a PROFIsafe telegram			
r61000	PROFINET Name of Station			
r61001	PROFINET IP of Station			

Troubleshooting and additional information

5.1 List of alarms and faults

Axxxxx Alarm

Fyyyyy: Fault

Table 5- 1 The most important alarms and faults of the safety functions

Number	Cause	Remedy
F01600	STOP A Triggered	STO Select and then deselect again.
F01650	Acceptance test required	Carry out acceptance test and create test certificate. Switch the Control Unit off and then on again.
F01659	Write task for parameter rejected	Cause: The converter should be reset to the factory setting. The resetting of the safety functions is, however, not allowed, because the safety functions are currently enabled.
		Remedy with operator panel:
		p0010 = 30 Parameter reset
		p9761 = ... Enter password for the safety functions.
		p0970 = 5 Reset Start Safety Parameter. The converter sets p0970 = 5 if it has reset the parameters.
	Then reset the converter to the factory setting again.	
A01666	Static 1 signal at F-DI for safe acknowledgment	F-DI to a logical 0 signal.
A01698	Commissioning mode active for safety functions	This message is withdrawn after the Safety commissioning has ended.
A01699	Shutdown path test required	After the next time that the "STO" function is deselected, the message is withdrawn and the monitoring time is reset.
F30600	STOP A Triggered	STO Select and then deselect again.

Table 5- 2 The most important alarms and faults

Number	Cause	Remedy
F01018	Power-up aborted more than once	1. Switch off the inverter power supply and switch it on again. 2. After this fault, the inverter powers up with the factory settings. 3. Recommission the inverter.
A01028	Configuration error	Explanation: The parameter assignments on the memory card were made with a different type of module (article no.). Check the module parameters and recommission if necessary.
F01033	Unit switchover: Reference parameter value invalid	Set the value of the reference parameter to a value other than 0.0 (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).

5.1 List of alarms and faults

Number	Cause	Remedy
F01034	Unit switchover: Calculation of the parameter values after reference value change unsuccessful	Select the value of the reference parameter so that the parameters involved can be calculated in the per unit notation (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).
F01122	Frequency at the probe input too high	Reduce the frequency of the pulses at the probe input.
A01590	Motor maintenance interval elapsed	Carry out the maintenance.
A01900	PROFIBUS: Configuration telegram faulty	Explanation: A PROFIBUS master is attempting to establish a connection with a faulty configuration telegram. Check the bus configuration on the master and slave side.
A01910 F01910	Fieldbus SS setpoint timeout	The alarm is generated when p2040 ≠ 0 ms and one of the following causes is present: <ul style="list-style-type: none"> • The bus connection is interrupted • The MODBUS master is switched off • Communications error (CRC, parity bit, logical error) An excessively low value for the fieldbus monitoring time (p2040)
A01920	PROFIBUS: Cyclic connection interrupt	Explanation: The cyclic connection to PROFIBUS master is interrupted. Establish the PROFIBUS connection and activate the PROFIBUS master with cyclic operation.
F03505	Analog input, wire break	Check the connection to the signal source for interrupts. Check the level of the signal supplied. The input current measured by the analog input can be read out in r0752.
A03520	Temperature sensor fault	Check that the sensor is connected correctly.
A05000 A05001 A05002 A05004 A05006	Power Module overtemperature	Check the following: <ul style="list-style-type: none"> - Is the ambient temperature within the defined limit values? - Are the load conditions and duty cycle configured accordingly? - Has the cooling failed?
F06310	Supply voltage (p0210) incorrectly parameterized	Check the parameterized supply voltage and if required change (p0210). Check the line voltage.
F07011	Motor overtemperature	Reduce the motor load. Check ambient temperature. Check sensor's wiring and connection.
A07012	I2t motor model overtemperature	Check and if necessary reduce the motor load. Check the motor's ambient temperature. Check thermal time constant p0611. Check overtemperature fault threshold p0605.
A07015	Motor temperature sensor alarm	Check that the sensor is connected correctly. Check the parameter assignment (p0601).
F07016	Motor temperature sensor fault	Make sure that the sensor is connected correctly. Check the parameterization (p0601).
F07086 F07088	Unit switchover: Parameter limit violation	Check the adapted parameter values and if required correct.

Number	Cause	Remedy
F07320	Automatic restart aborted	Increase the number of restart attempts (p1211). The current number of start attempts is shown in r1214. Increase the wait time in p1212 and/or monitoring time in p1213. Create ON command (p0840). Increase the monitoring time of the power unit or switch off (p0857). Reduce the wait time for resetting the fault counter p1213[1] so that fewer faults are registered in the time interval.
A07321	Automatic restart active	Explanation: The automatic restart (AR) is active. During voltage recovery and/or when remedying the causes of pending faults, the drive is automatically switched back on.
F07330	Search current measured too low	Increase search current (P1202), check motor connection.
A07400	V _{DC_max} controller active	If the controller is not to intervene: <ul style="list-style-type: none"> • Increase the ramp-down times. • Deactivate the V_{DC_max} controller (p1240 = 0 for vector control, p1280 = 0 for V/f control).
A07409	V/f control, current limiting controller active	The alarm automatically disappears after one of the following measures: <ul style="list-style-type: none"> • Increase the current limit (p0640). • Reduce load. • Increase the ramp-up time to the speed setpoint.
F07426	Technology controller actual value limited	<ul style="list-style-type: none"> • Adapt the limits to the signal level (p2267, p2268). • Check the actual value scaling (p2264).
A07444	PID autotuning is activated	Automatic setting of the PID controller (autotuning) is active (p2350 > 0). The alarm disappears automatically after completion of the autotuning.
F07445	PID autotuning canceled	The inverter has canceled the automatic setting of the PID controller (autotuning) because of a fault. Remedy: Increase p2355 and restart autotuning.
F07801	Motor overcurrent	Check current limits (p0640). V/f control: Check the current limiting controller (p1340 ... p1346). Increase acceleration ramp (p1120) or reduce load. Check motor and motor cables for short-circuit and ground fault. Check motor for star-delta connection and rating plate parameterization. Check power unit / motor combination. Select flying restart function (p1200) if switched to rotating motor.
A07805	Drive: Power unit overload I2t	<ul style="list-style-type: none"> • Reduce the continuous load. • Adapt the load cycle. • Check the assignment of rated currents of the motor and power unit.
F07807	Short-circuit detected	<ul style="list-style-type: none"> • Check the inverter connection on the motor side for any phase-phase short-circuit. • Rule out that line and motor cables have been interchanged.
A07850	External alarm 1	The signal for "external alarm 1" has been triggered. Parameter p2112 defines the signal source of the external alarm. Remedy: Rectify the cause of this alarm.

5.1 List of alarms and faults

Number	Cause	Remedy
F07860	External fault 1	Remove the external causes for this fault.
F07900	Motor blocked	<ul style="list-style-type: none"> • Make sure that the motor can rotate freely. • Check the torque limit: r1538 for a positive direction of rotation; r1539 for a negative direction of rotation.
F07901	Motor overspeed	Activate precontrol of the speed limiting controller (p1401 bit 7 = 1).
F07902	Motor stalled	<p>Check whether the motor data has been parameterized correctly and perform motor identification.</p> <p>Check the current limits (p0640, r0067, r0289). If the current limits are too low, the drive cannot be magnetized.</p> <p>Check whether motor cables are disconnected during operation.</p>
A07903	Motor speed deviation	<p>Increase p2163 and/or p2166.</p> <p>Increase the torque, current and power limits.</p>
A07910	Motor overtemperature	<p>Check the motor load.</p> <p>Check the motor's ambient temperature.</p> <p>Check the KTY84 or PT1000 sensor.</p>
A07920	Torque/speed too low	The torque deviates from the torque/speed envelope curve.
A07921	Torque/speed too high	<ul style="list-style-type: none"> • Check the connection between the motor and the load. • Adapt the parameterization corresponding to the load.
A07922	Torque/speed out of tolerance	
F07923	Torque/speed too low	
F07924	Torque/speed too high	<ul style="list-style-type: none"> • Check the connection between the motor and the load. • Adapt the parameterization corresponding to the load.
A07927	DC braking active	Not required
A07980	Rotary measurement activated	Not required
A07981	No enabling for rotary measurement	<p>Acknowledge pending faults.</p> <p>Establish missing enables (see r00002, r0046).</p>
A07991	Motor data identification activated	Switch on the motor and identify the motor data.
F08501	Setpoint timeout	<ul style="list-style-type: none"> • Check the PROFINET connection. • Set the controller to RUN mode. • If the error occurs repeatedly, check the monitoring time set (p2044).
F08502	Monitoring time, sign-of-life expired	<ul style="list-style-type: none"> • Check the PROFINET connection.
F08510	Send configuration data not valid	<ul style="list-style-type: none"> • Check the PROFINET configuration
A08511	Receive configuration data not valid	
A08526	No cyclic connection	<ul style="list-style-type: none"> • Activate the control with cyclic operation. • Check the parameters "Name of Station" and "IP of Station" (r61000, r61001).
A08565	Consistency error affecting adjustable parameters	<p>Check the following:</p> <ul style="list-style-type: none"> • IP address, subnet mask or default gateway is not correct. • IP address or station name used twice in the network. • Station name contains invalid characters.

Number	Cause	Remedy
F08700	Communications error	<p>A CAN communications error has occurred. Check the following:</p> <ul style="list-style-type: none"> • Bus cable • Baud rate (p8622) • Bit timing (p8623) • Master <p>Start the CAN controller manually with p8608 = 1 after the cause of the fault has been resolved!</p>
F13100	Know-how protection: Copy protection error	<p>The know-how protection and the copy protection for the memory card are active. An error occurred during checking of the memory card.</p> <ul style="list-style-type: none"> • Insert a suitable memory card and switch the inverter power supply temporarily off and then on again (POWER ON). • Deactivate the copy protection (p7765).
F13101	Know-how protection: Copy protection cannot be activated	Insert a valid memory card.
F30001	Overcurrent	<p>Check the following:</p> <ul style="list-style-type: none"> • Motor data, if required, carry out commissioning • Motor's connection method (Y / Δ) • V/f operation: Assignment of rated currents of motor and Power Module • Line quality • Make sure that the line commutating reactor is connected properly • Power cable connections • Power cables for short-circuit or ground fault • Power cable length • Line phases <p>If this doesn't help:</p> <ul style="list-style-type: none"> • V/f operation: Increase the acceleration ramp • Reduce the load • Replace the power unit
F30002	DC-link voltage overvoltage	<p>Increase the ramp-down time (p1121). Set the rounding times (p1130, p1136). Activate the DC-link voltage controller (p1240, p1280). Check the line voltage (p0210). Check the line phases.</p>
F30003	DC-link voltage undervoltage	Check the line voltage (p0210).
F30004	Converter overtemperature	<p>Check whether the inverter fan is running. Check whether the ambient temperature is in the permissible range. Check whether the motor is overloaded. Reduce the pulse frequency.</p>
F30005	I2t inverter overload	<p>Check the rated currents of the motor and Power Module. Reduce current limit p0640. When operating with V/f characteristic: Reduce p1341.</p>

5.1 List of alarms and faults


Number	Cause	Remedy
F30011	Line phase failure	Check the inverter's input fuses. Check the motor cables.
F30015	Motor cable phase failure	Check the motor cables. Increase the ramp-up or ramp-down time (p1120).
F30021	Ground fault	<ul style="list-style-type: none"> • Check the power cable connections. • Check the motor. • Check the current transformer. • Check the cables and contacts of the brake connection (a wire might be broken).
F30027	Time monitoring for DC link pre-charging	Check the line voltage. Check the line voltage setting (p0210).
F30035	Overtemperature, intake air	<ul style="list-style-type: none"> • Check whether the fan is running. • Check the fan filter elements. • Check whether the ambient temperature is in the permissible range.
F30036	Overtemperature, inside area	
F30037	Rectifier overtemperature	See F30035 and, in addition: <ul style="list-style-type: none"> • Check the motor load. • Check the line phases
A30049	Internal fan defective	Check the internal fan and if required replace.
F30059	Internal fan defective	Check the internal fan and if required replace.
F30074	Communications fault between Control Unit and Power Module	The 24V voltage supply of the inverter (terminals 31 and 32) was interrupted briefly. Please check the voltage supply and the wiring.
A30502	DC link overvoltage	<ul style="list-style-type: none"> • Check the device supply voltage (p0210). • Check the line reactor dimensioning
A30920	Temperature sensor fault	Check that the sensor is connected correctly.
A50001	PROFINET configuration error	A PROFINET control is attempting to establish a connection with a faulty configuration telegram. Check to see whether "Shared Device" is activated (p8929 = 2).
A50010	PROFINET name of station invalid	Correct the name of station (p8920) and activate (p8925 = 2).
A50020	PROFINET: Second control missing	"Shared Device" is activated (p8929 = 2). However, only the connection to a PROFINET control is present.

For further information, please refer to the List Manual.



Overview of the manuals (Page 84)

5.2 Spare parts

Spare part	Article number	
 <p>5 sets of I/O terminals, 1 set of front doors and 1 piece operator panel blind cover</p>	6SL3200-0SK41-0AA0	
 <p>Screening plates including mounting accessories</p>	Frame size AA	6SL3266-1ER00-0KA0
	Frame size A	6SL3266-1EA00-0KA0
	Frame size B	6SL3266-1EB00-0KA0
	Frame size C	6SL3266-1EC00-0KA0
 <p>1 set of connector plugs for mains, motor and breaking resistor</p>	Frame size AA, A	6SL3200-0ST05-0AA0
	Frame size B	6SL3200-0ST06-0AA0
	Frame size C	6SL3200-0ST07-0AA0
 <p>Fan unit for the heat sink, consists of plugable frame with built in fan</p>	Frame size A	6SL3200-0SF12-0AA0
	Frame size B	6SL3200-0SF13-0AA0
	Frame size C	6SL3200-0SF14-0AA0
 <p>Top fan, consists of top cover with built in fan</p>	Frame size AA	6SL3200-0SF38-0AA0
	Frame size A	6SL3200-0SF40-0AA0
	Frame size B	6SL3200-0SF41-0AA0
	Frame size C	6SL3200-0SF42-0AA0



You will find more information in the Internet at:

Spares on Web (<https://www.automation.siemens.com/sow?sap-language=EN>)

5.3 Technical support

 +49 (0)911 895 7222

 +44 161 446 5545

 +39 (02) 24362000

 +34 902 237 238

 +33 (0) 821 801 122



You can find additional telephone numbers for Technical Support in the Internet:

Product support (<http://www.siemens.com/automation/service&support>)


5.4 Overview of the manuals



Manuals with additional information that can be downloaded

- SINAMICS G120C compact operating instructions
(<https://support.industry.siemens.com/cs/ww/en/view/109477359>)
Commissioning the inverter (this manual).

- SINAMICS G120C operating instructions.
(<https://support.industry.siemens.com/cs/ww/en/view/109478830>)
Installing, commissioning and maintaining the inverter. Advanced commissioning

- EMC installation guideline
(<http://support.automation.siemens.com/WW/view/en/60612658>)
EMC-compliant control cabinet design, potential equalization and cable routing

- SINAMICS G120C List Manual
(<https://support.industry.siemens.com/cs/ww/en/view/109477254>)
Parameter list, alarms and faults. Graphic function diagrams

- "Fieldbus" function manual
(<https://support.industry.siemens.com/cs/ww/en/view/109477369>)
Configuring fieldbuses

- "Safety Integrated" function manual
(<https://support.industry.siemens.com/cs/ww/en/view/109477367>)
Configuring PROFIsafe. Installing, commissioning and operating fail-safe functions of the inverter.
- BOP-2 operating instructions
(<https://support.industry.siemens.com/cs/ww/en/view/42185248>)
Using the operator panel.

- IOP operating instructions
(<https://support.industry.siemens.com/cs/ww/en/view/109478559>)
Using the operator panel, mounting the door mounting kit for IOP.

- Accessories manual (<https://support.industry.siemens.com/cs/ww/en/ps/13225/man>)
Installation descriptions for inverter components, e.g. line reactors and line filters. The printed installation descriptions are supplied together with the components.


Index

A

Agitators, 40
Analog input, 26
Analog output, 26

B

BOP-2
 Menu, 47
 Symbols, 47
Braking resistor, 15
Bus termination, 24

C

Cable protection, 19
Centrifuge, 40
Chain conveyors, 40
Commutation notches, 15
Compressor, 40
Control terminals, 26
Conveyor belt, 40
Crushers, 40
cUL-compliant installation, 22

D

Digital input, 26
Digital output, 26
Dimensioned drawings, 11
Drilling pattern, 12

E

EDS (electronic data sheet), 36
Extruder, 40

F

Factory assignment, 26
Fans, 40
Fieldbus interfaces, 24

Functions

 BOP-2, 47
 Fuse, 19

G

Getting Started, 84
GSD (Generic Station Description), 36
GSDML (Generic Station Description Markup Language), 36

H

Hardware Installation Manual, 84
Harmonics, 15

I

Interfaces, 24

K

Kneaders, 40

L

Line reactor, 15
List Manual, 84
Locked-rotor (starting) torque, 12

M

Menu
 BOP-2, 47
 Operator panel, 47
Mills, 40
Minimum spacing
 Above, 11
 Below, 11
 Front, 11
 Side by side, 11
Mixers, 40
MotID (motor data identification), 42, 45
Motor data
 Identify, 45

- Identifying, 42
- measure, 45
- Measuring, 42
- Motor temperature sensor, 26

O

- Operating instruction, 6
- Operating Instructions, 84
- Operator panel
 - BOP-2, 47
 - Menu, 47
- Output choke, 15
- Overvoltage protection, 15

P

- Parameter number, 49
- Parameter value, 49
- Power Modules
 - Dimensioned drawings, 11
- Procedure, 6
- Pump, 40

R

- Roller conveyors, 40
- Rotary furnace, 40

S

- Settling time, 40
- Shield plate, 12
- Speed
 - change with BOP-2, 47
- Spindle, 40
- STARTER
 - Download, 38, 38
- Switching-on a motor with BOP-2, 47
- Symbols, 6


T

- Temperature sensor, 26
- Terminal strip
 - Factory setting, 26
- Torque accuracy, 40

U

- UL-compliant installation, 22
- User interfaces, 24

**SINAMICS G120C
DOCUMENTATION PACK**



Printed in the United Kingdom

Further information

SINAMICS inverters:
www.siemens.com/sinamics

Safety Integrated:
www.siemens.com/safety-integrated

PROFINET:
www.siemens.com/profinet

Siemens AG
Digital Factory
Motion Control
Postfach 3180
91050 ERLANGEN
GERMANY

Subject to change without prior notice
© Siemens AG 2011-2016

For additional
information on
SINAMICS G120,
scan the QR code.

